



Vacuum Installation Guide

Bags • Belts • Brush Rollers

SAFETY

Unplug the vacuum before servicing

Allow unit to cool before working

Work on a flat, stable surface

VACUUM BAG INSTALLATION

Open the bag compartment

Remove old bag from holder

Insert new bag collar firmly into intake

Ensure tight seal — no gaps

Close compartment securely

BELT INSTALLATION

Lay vacuum flat and remove bottom plate

Remove brush roller

Slide old belt off motor shaft

Install new belt onto motor shaft

Stretch belt onto roller and reinstall

Reassemble base plate

BRUSH ROLLER INSTALLATION

Remove existing roller

Insert new roller into belt loop

Align ends into housing slots

Ensure roller spins freely

Reattach bottom plate

FINAL CHECK

Brush roller spins freely

Belt aligned correctly

Bag sealed properly

Vacuum runs smoothly

For additional help visit www.ElectricVac.com