


1




**Connect the pole
adapter and rake head**

2



**Connect the metal braces
to rake head and pole adapter**

3



**Connect the pole
adapter and rake head**

4



Ready to use