ASSEMBLY INSTRUCTIONS




- ◆ Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have resulted during shipping. If there is a defect in the wire, do not attempt installation.
- ◆ Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.




If you need further assistance, please contact us by Email: customersupport@superiordecorinc.com

TOOLS REQUIRED



HARDWARE INCLUDED











Mounting Unit


Ball Nuts


Mounting Screws

Wire Nuts


* PARTS SHOWN MAY DIFFER SLIGHTLY PER LIGHT FIXTURE

EXPLODED PARTS






STEP 2 Attach the **iron rack** onto **fixture** using **ball nuts**.




STEP 3


Unscrew the **ball nuts** from the **mounting unit**. Use the **mounting screws** to attach the **mounting unit** to the junction box (not included).



STEP 4

Make the electrical connection from the junction box (not included) to the **fixture**. Connect the ground wire to the **mounting unit** using the preinstalled green ground screw. Next, connect the live wire, neutral wire and ground wires with the supplied **wire nuts**. Secure with electrical tape.





STEP 5

Secure the **fixture** to the **mounting unit** with the **ball nuts**.

