CARE AND MAINTENANCE

Wipe clean with a soft cloth dampened in water and a mild soapy solution. Wipe dry with a clean and dry cloth.

this rattan basket requires no maintenance

however, by keeping the furniture clean and storing it properly you can enjoy it year after year.

If there are any questions relating to missing parts, assembly issues or replacements, please send a detailed email to hello@happimess.com

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item Should be assembled on a soft surface to prevent scratching the finish during assembly
- * This Item may require periodic tightening


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QTY
А	Side Frame		1
В	Bottom Base		1
С	Inter liner		1
D	Top Lid		1
Е	Stopper		4
F	Allen Bolt	12 mm 60 mm 14 mm 66 mm	4
G	Washer		4
Н	Screw		4
I	Allen Key		1

happimess

Item #: HPM9003

Product Dimensions: W31.5" x D18.7" x H18.7"



Weight Capacity: 33.06 Lbs

Warning: Do not stand on Basket

Warning: Do not sit on basket







PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware content list. If any parts is missing or damaged, do not attempt to assemble the product Estimated Assembly Time 10 Minutes.

