


SKU:N711P241277



- 1.Note:This is not a clothing storage cabinet and it is not recommended to use it as a clothing storage cabinet.
- 2.All cabinets come with TRD,stainless steel or our "L-Bracket" when shipped.

1. Thank you for choosing *our products*.

2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expectations or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solution or answer any questions you may have.

Recommendations Before Beginning Assembly



- Read instructions, cover to cover



- Have 2-4 adults on hand for assembly depending on product size



- Do not assemble directly on flooring or carpet



- Assemble on a clean non-marring surface (example: packing foam)



- Save all packaging until finished

3. Assembly Notice:

- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the

hardware spill in the box.

- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- **IMPORTANT:** When setting up your product, **DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING.** Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

Care & Maintenance



Do not put hot items directly on furniture surface



Do not clean furniture with harsh cleansers or polish



Do not place furniture under direct sunlight



Do not place furniture near heating or cooling vents



Do not write on furniture without a padded barrier to protect the surface



Do not place furniture outside. For indoor use only



Not for commercial use. For residential use only



Stains may be removed with mild soap solution and damp cloth




Children should not climb or jump on the furniture





Dust and pick-up spills using a clean, non-colored, lint-free cloth











Caution






- This product contains small components. Please ensure that they are kept away from small children.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.




SKU:N711P241277




①  x1	②  x1		
③  x1	④  x1	⑤  x1	⑥  x2
⑦  x2	⑧  x2	⑨  x2	⑩  x1
⑪  x2	⑫  x1		



 Ø 6x35mm AX4	 Ø 15x9 mm BX4	 Ø6x30mm CX6	 Ø5x50mm DX2	 EX1
 Ø 8x60mm FX6	 Ø3x14mm GX8	 HX8	 KX4	 LX4
 JX8	 Ø 4x14mm MX48	 NX4	 Ø4x20mm OX4	 RX6
 P1  P2 x2  P3  P4  P5 PX2		 TX1		


STEP 1





 Ø6x30mm CX2	 Ø5x50mm DX2	 EX1
---	---	--

STEP 2




	
Ø6x35mm	Ø6x30mm
AX4	CX4

STEP 3







Ø 15x10mm
B X4

STEP4




STEP 5




 Ø8x60mm FX6	 RX6	 TX1
---	--	--



STEP 6




STEP 7
X2




STEP 8



NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.





STEP 9



LX4	MX8	NX2	OX2


STEP 10




NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.



Ø4x14mm
MX16

STEP 11



	
JX8	Ø3x14mm
	GX8


STEP 12



		
P 1	P 2	P 3
P X2		

STEP 13

WALL




	
J 3	J 5
J X1	

Assembly Steps(EN) / Montageschritte(DE)

HOW TO ADJUST THE HINGES TO
ALIGN THE DOORS IF NEEDED.


STEP 1

Open the door.




STEP 2

Adjust the door panels upward or downward



STEP 3

Adjust the flush between door panel and side panel



STEP 4

Adjust the Gap between door panel and side panel

