
## ASSEMBLY INSTRUCTIONS

# TEAK DINING SET IT-610588T





Scan me for assembly video A gift is waiting for you!

#### **Customer Service Information**

Please email us at <u>info@cambridge-casual.com</u> for assembly tips, report damage, or request parts. For faster response, please write down item number, code for missing parts, attach the purchase receipt and picture of damaged parts.


Toll free number : 1-888-287-4275 from 9:00am to 5:00pm CST (Monday to Friday)

#### **GENERAL INFORMATION & TIPS**


- 1. Please read the assembly instructions prior to assembling the table.
- 2. To avoid damage, assemble the table on a non-abrasive surface such as carpet.
- 3. Make sure all bolts tightly fastened before the table is used.
- 4. This table is not for commercial use.


Please make sure you have all parts before beginning assembly. Please wait until all steps are completed before tightening bolts.

#### PARTS AND HARDWARE LIST



#### TO UNFOLD THE CHAIR





#### **GENERAL INFORMATION & TIPS**


- 1. Please read the assembly instructions prior to assembling the table.
- 2. To avoid damage, assemble the table on a non-abrasive surface such as carpet.
- 3. Make sure all bolts tightly fastened before the table is used.
- 4. This table is not for commercial use.


Please make sure you have all parts before beginning assembly. Please wait until all steps are completed before tightening bolts.

#### **TOOLS REQUIRED**

8" Philips screwdriver (Not provided).
For tightening all bolts and screws.

### PARTS AND HARDWARE LIST





STEP 5	STEP 6 Hardware nut
	Position the bolt at the bottom of the table with the hole in the rail and then, turn and tighten the wooden handle under the rail. The hardware nut under the table should be tight, but not clamped against the bar, leaving space between the hardware nut and the bar for the table top to turn easily.
Lift the side table leaf and turn it counterclockwise. *Two people are required to turn the table top.	**Do not move or mobile the table when it is opened and in use, fold the table top down before moving it.
TO FOLD THE TABLE	
Turn and loosen the wooden handle under the rail until the table top comes off, then Lift the table top slightly so that the boltl release out of the hole, then turn it clockwise and thread the rail into the leg frame.	

