

## **Holiscapes® LED Lighted Colored Easter Eggs**

### **Kit includes:**

- 5 Pastel colored eggs
- 5" High Ground Stake
- 5" twine for hanging use.

### **Operating Instructions**

1. Open battery compartment in egg base by removing 2 screws
2. Place (3) AA batteries into battery compartment (not included)
3. Replace battery compartment cover and tighten screws to secure
4. Choose which operating mode you wish to use:
  - a. Off
  - b. Color Fade
  - c. Static Color
5. Your egg operates on a 5/19 timer. Once turned on in either color fade or static mode, it will remain lighted for 5 hours and turn off for 19 hours
6. Your egg will turn on again after 19 hours with no further action by you and will continue to do so until batteries are depleted
7. To control the time of day your eggs will turn on; simply turn on at time of day you wish to begin. To reset – turn off and then back on at desired time.

### **Other Information:**

- Your egg has a hole in the base by design. Should any moisture collect in the egg, it can drain through this opening. For best operation, do not cover the hole.
- To use the ground stakes – position tabs on top of the stakes to the corresponding holes on the bottom of the egg and insert. Turn stake clockwise to lock into egg. To remove stake – turn counterclockwise and pull stake away from egg.
- To use the included cords for hanging the eggs. Feed each side of the cord through the 2 holes at the top of the egg. Tug lightly to make sure the ends are secure on the inside of the eggs. Hang away!