


John Deere Z375R ZTrak™

Parts and Maintenance Information



| Key | Description | Part Number | Lowe's Item # |
|-----|-------------------------|-------------|---------------|
| 1. | 54 inch Mower Blade | GY20685 | 698348 |
| 2. | 54 inch Mower Deck Belt | GX26422 | 733644 |
| 3. | Oil Filter | GY20577 | 228877 |
| 4. | Oil | TY22029 | 48763 |
| 5. | Fuel Filter | GY20709 | 228878 |
| 6. | Air Filter | GY21057 | 29180 |
| 7. | MulchControl™ Kit | BM24994 | 729667 |

John Deere Z375R ZTrak™

Parts and Maintenance Information

| After 8 Hours | Every 100 Hours or Annually (Whichever Comes First) |
|--|---|
| Check mower deck level | Replace air filter element(s) |
| Every 50 hours or Annually (Whichever Comes First) | Replace fuel filter |
| Change engine oil | Check mower belt |
| Change engine oil filter | Sharpen / replace mower blades |
| Lubricate mower deck spindles | Clean underside of deck |
| Lubricate mower idler arm | Check tire pressure |
| Check mower deck level | Clean engine cooling fins |
| | Every 200 Hours |
| | Check / adjust engine valve clearance. See your John Deere dealer for this service. |

For complete parts information for ZTrak™ Mowers: Visit your local John Deere Dealer or www.Deere.com

*Refer to Operators Manual for a complete listing of service intervals.