
ASSEMBLY INSTRUCTION

N723P212569



CUSTOMER SERVICE

Questions, Missing parts, Assembly help?

No need to return the product, we will gladly help and ship your replacement parts free of charge.

PRE-ASSEMBLY INFORMATION

Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

NOTICE

- 1.Please assemble it AFTER all boxes are received.
- 2.Please do not throw away any of the packages or the instruction until the sofa is fully assembled.
- 3. Please keep children away from the plastic bags or any small pieces of stuff.
- 4.Some key parts of our product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to take out all parts.
- 5.Please do not open the compressed packages until your sofa frame is completely assembled.
- 6.As the cushions are all vacuum compressed, there will be some wrinkles. Please give them up to 72 hours to reach its original size and the wrinkles will basically disappear.
- 7.DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING. Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- 8.Do not over tighten screws and bolts to avoid stripping.



1 adult recommended




Takes about 30 minutes to assemble



Weight capacity of each seat: 400LBS


COMPONENTS



HARDWARE			
NO	DESCRIPTION	SKETCH	QTY
1	Screws 6x20	•	8
2	Screws 6x50		6
3	Washer Ø6xØ14x1	0	12
4	Washer Ø6xØ18x3	•	8
5	Nut 6	•	6
6	Turntable 190x190		1
7	Allen key 4		2
8	Wrench 10		1

COMPONENTS

N723P212569



ASSEMBLY STEPS

