



Thank you for choosing Sunnydaze Decor. If you have any questions, comments or concerns please feel free to contact us by phone at: **888-881-4668**, by email: [customerservice@serenityhealth.com](mailto:customerservice@serenityhealth.com), or you could also email us via our contact us page at: [www.serenityhealth.com/contact-us/](http://www.serenityhealth.com/contact-us/).

We stand behind our brand and the quality of the items we sell. We will send new parts, or replace products at our discretion within the one year warranty period. Before we can help, you will need to provide proof of purchase with the date of purchase and photos of the defective merchandise. We will use the photos to determine the cause of defect and for future quality control.

## Slate Fountain Instruction

### Item#: GSI-842

#### Warning and Safety Concerns


- \* Keep fountain out of reach of children.
- \* Use proper power source as indicated on water pump label.
- \* Keep electrical cords away from all heat sources. Do not place electrical cords in high temperatures.
- \* Check water level at pump location regularly. To avoid damage the pump must be fully submerged.

#### PARTS LIST

- A: Base 1PC
- B: Pump 1PC
- C: Fountain Body 1PC
- D: L-shape Cover 1PC
- E: Copper Tube 3PC
- F: Clock 1PC
- G: Cover for Spot light 1pc
- H: Pebbles 1BAG

#### ASSEMBLY INSTRUCTIONS

1. Locate the base in the flat location. Add water to the level indicated in.
2. A. Insert the pump and connect the pump with hose.  
B. Put the fountain body onto base
3. A. Place the L-shape cover onto top of fountain body
4. A. Insert 3pcs copper tube into the holes of fountain body  
B. Connect the clock into copper tubes
5. A. Insert the spot light, then place the cover of spot light  
B. Plug the power cord into an outlet



#### TROUBLESHOOTING :

Pump operates, but no water flow:

- \* Make sure pump is fully submerged in water. If there is still no water flow please turn off the power of the transformer, repeat this step several times.

Water speed:

- \* To change the water speed, simply adjust the switch control located on the pump housing.

Noise from fountain:

- \* Check water level and make sure the pump is completely submerged

Light does not shimmer:

- \* Check the light bulb and make sure it is connected to socket.