


Fixing Hole Size & Installation


▼ Fixing hole size

Unit: mm




(1) Wood/Steel

▼ Inserting the battery




▼ Removing the battery



▼ Installation

* Suitable thickness

Steel: 0.5~2mm / Wood: 16~20mm



(2) Wood