

Limited Warranty Information

Thank you for choosing an Alpine product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

- **Water Damage**

Alpine products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage and is considered negligence and will, therefore not be covered under this warranty. The use of "hard water" and/or caustic cleaners can affect the paint or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of Alpine Corporation

- **Paint & Color (Retention and/or Loss)**

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading within the first year from date of purchase with the above exclusion.

- **Procedure/Service**

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. If that is not an option, you can contact Alpine Corporation at www.alpine4u.com. When contacting Alpine Corporation, you must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department. **Item is covered under two year limited warranty from the date of purchase. If your purchase was after our 30-day grace period, payment information will be requested for shipping charges.**

- **Not Covered Under Warranty**

The limited warranty will NOT cover cases of damages due to

1. Inadequate care and/or neglect
2. Environmental and/or natural elements
3. Immersion in water, unless specified
4. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim.



Owner's Manual
Item # WIN1606

Tree Trunk Fountain with Lights



Assembling and Using Your Product


Unpack all components carefully. Please check to ensure all parts have been removed from the packaging.

Components:

- A. Fountain (x1)
- B. Transformer (x1)
- C. Submersible Pump (x1)
- D. Back Cover (x1)

Assembly:

1. Place the Fountain (A) on a smooth, level surface.
2. Remove the Submersible Pump (C) from its packaging and adjust flow control to the lowest setting to avoid splashing until the fountain is completely assembled.
3. Pull the plastic tube from back opening of Fountain (A) and connect to Pump (C).
4. Place the Pump (C) suction feet down into the bottom of the reservoir through the opening at the back of the fountain.
5. Pull the LED light cord from the back opening of the Fountain (A) and connect to Transformer (B).



6. Slide Back Cover (D) into fountain back opening with cords tucked into notch.
7. Carefully fill with water. We recommend using distilled water to prevent scale build-up.
8. Congratulations, your fountain is now complete. Plug transformer and power cord for the pump into your local power supply to turn on and enjoy!

IMPORTANT: Make sure no water is near the plug and always keep the power source in a dry place.

The first time you operate the pump it can take up to 5 minutes for the air to be completely expelled and water begins to flow properly.

Don't forget to add water regularly as water will evaporate over time.

Trouble Shooting and Cautions

If you have any questions and/or problems, please contact the retail store where you purchased this fountain.

If your pump fails to run

- Check circuit breaker or try a different outlet to ensure pump is receiving power.
- Check the pump discharge and tubing for any kinks or obstructions.
- Any buildup obstructing the water flow can be flushed with a garden hose.
- Check the rotor by removing the front cover and plate to access impeller area.

Turn the rotor and make sure that the rotor is not jammed or broken.

If your pump "spews" or splashes

- Check the water level to make sure the pump is completely submerged and there is enough water in the basin to operate your fountain. Not having enough water will cause your pump to spew or splash.

If your pump is making abnormal loud noises

1. Disconnect the pump from the electrical power and remove front cover.
2. Carefully grip impeller and gently pull impeller/rotor assembly from pump housing.
3. Rinse the impeller/rotor assembly and clean the cavity with clean water. If breakage or damage is found, contact your local retailer for parts.

Fountain Care

- We recommend using Alpine Item PPL102's all-natural cleansing formula to eliminate foam, lime scale, and calcium buildup; fight mineral deposits; leave water crystal clear; help prevent staining; remove organic contaminants; and treat discolored water. This formula helps prevent pump damage due to hard water build up. For more information, please visit www.alpine4u.com.

Caution

- **Always unplug pump and transformer from power before cleaning and handling.**
- **Use with clean water only, do not place fountain or parts in other liquids.**
- **Periodically change water and clean the pump to keep free from micro-organisms.**
- **Disconnect and store in a dry place if not in use for extended time periods.**
- **Do not lift, carry, or pull the pump by the power cord.**
- **NEVER LET THE PUMP RUN DRY.**