



Bottom DOUBLE-CAR GARAGE DOOR SEAL

Easy to Use:

1. Raise garage door and remove old seal and fasteners.
2. Beginning at one end, fasten door bottom along bottom of garage door. Install so that long flap faces outside of garage. Fasten with enclosed galvanized nails. (Application on steel doors requires drilled pilot holes on the garage door and sheet metal screws to apply this garage door bottom).
3. Trim excess at ends of door with knife or scissors.

To completely seal your garage door, M-D offers other quality products designed for top and sides.

Fácil de Usar :

1. Levante la puerta de garaje y quite la base y sujetadores viejos.
2. Empezando a un extremo, coloque la base nueva a lo largo de la parte inferior de la puerta de garaje. Instale de tal manera que la aleta larga quede hacia afuera. Fije con los clavos galvanizados proveídos. (La aplicación en puertas de acero requiere taladrar agujeros antemano y el uso de tornillos de metal para instalar este tipo de base para puerta de garaje.)
3. Con un cuchillo o con tijeras, recorte el material sobrante de los extremos de la puerta.

Para terminar de sellar su puerta de garaje, M-D ofrece otros productos de calidad diseñados especialmente para la parte superior y los costados.

QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

