

PRORUN®


////// *POWER and RELIABILITY™*

GAS///

POLE SAW

MODEL: PPS210

PARTS LIST



Please let us know what you think.
To leave a review and see our full line of products, visit:

proruntech.com ★ ★ ★ ★ ★


1-844-905-0882, info@proruntech.com

Version: B - Issue Date: 2023/03/15

**SPARE PARTS / CHASSIS AND ENCLOSURE****FUEL TANK**


Part Number: 20070209

No.	Description	Qty
83	Fuel Tank	1

**FUEL TANK BASE ASSEMBLY**


Part Number: 68821701

No.	Description	Qty
84	Rubber Bump	4
85	Fuel Tank Housing	1
86	Screw M5x25	4

**FUEL TANK CAP ASSEMBLY**


Part Number: 20072561

No.	Description	Qty
80	Fuel Tank Cover	1
81	Gasket Rubber	1
82	Anti-Falling Board	1

**SPARE PARTS / STARTING MECHANISM****SPARK PLUG**

Part Number: 20079314


No.	Description	Qty
29	Spark Plug	1



**SPARE PARTS / STARTING MECHANISM****STARTER ASSEMBLY**


Part Number: 68821702

No.	Description	Qty
2	Pull Cord Sheath	1
3	Starter Cover	1
5	Starter Pull Cord	1
6	Start Handle	1
7	Coil Spring	1
8	Start Pulley	1
9	Start Spring	1
10	Ratchet Wheel	1
11	Plate Washer	1
12	Self-Tapping Screw ST4.8x16	1

**STARTER GRIP AND ROPE ASSEMBLY**


Part Number: 68821703

No.	Description	Qty
5	Starter Pull Cord	1
6	Start Handle	1

**IGNITION ASSEMBLY**

Part Number: 20050977


No.	Description	Qty
36	Igniter	1
35	Spark Plug Cover	1



**SPARE PARTS / CARBURETOR****CARBURETOR ASSEMBLY**


Part Number: 68821705

No.	Description	Qty
74	Carburetor	1
73	Gasket \ Carburetor	1

**SPARE PARTS / THROTTLE CONTROL, HANDLE, AND SHAFTS****THROTTLE HANDLE ASSEMBLY (H1)**

Part Number: 20072569


No.	Description	Qty
44	Nut M5	4
45	Plastic Handle / LH	1
46	Spring / Trigger	1
47	Wire Cable A	1
48	Wire Cable B	1
49	Bushing	1
50	Throttle Cable Assembly	1
51	Plastic Handle / RH	1
52	Screw M5x14	2
53	Self-Tapping Screw ST3.5x9.5	2
54	Self-Tapping Screw ST4.2x10	2
55	Screw M5x14	2
56	Trigger	1
57	Switch	1
58	Lock Trigger	1
59	Spring / Trigger	1



**SPARE PARTS / THROTTLE CONTROL, HANDLE, AND SHAFTS****FRONT LOOP HANDLE ASSEMBLY**


Part Number: 20071772

No.	Description	Qty
45	Front Handle	1
46	Nut M5	2
47	Handle Base	1
48	Clamp	1
49	Screw M5x28	2
50	Lock Washer 5	2
51	Plate Washer $\Phi 5 \times \phi 12 \times 1.5$	2
52	Plate Washer $\Phi 5 \times 11 \times 2$	1
53	Plate Washer $\Phi 5 \times \phi 12 \times 1.5$	1
54	Self-Tapping Screw ST4.8x19	2

**SPARE PARTS / TRIMMER HEAD, GUARD, AND BUSH CUTTER****DRIVER SHAFT**


Part Number: 20054026

No.	Description	Qty
22/55	Driver Shaft	1

**BACK SHAFT ASSEMBLY**

Part Number: 20077191

No.	Description	Qty
8/20	Back Aluminum Tubing	1
9/21	Rubber / Shaft	3




SPARE PARTS / TRIMMER HEAD, GUARD, AND BUSH CUTTER

CONNECTOR ASSEMBLY

Part Number: 20085833


No.	Description	Qty
10	Connector Assembly	1
11	Screw M5x25	1
12	Screw M5x12	1
13	Screw M6x50	1
14	Plate Washer 6	1
15	Lock Knob	1
16	Nut M6	1
17	Latch Bolt	1



HARNESS CLAMP ASSEMBLY

Part Number: 68821706

No.	Description	Qty
2	Sleeve 26	1
3	Clamp	1
4	Nut M5	1
5	Screw M5x22	1
6	Harness Clamp	1




SPARE PARTS / BAR AND CHAIN ASSEMBLY

10 INCH GUIDE BAR

Part Number: 30001374


No.	Description	Qty
44	10 Inch Guide Bar	1



10 INCH SAW CHAIN

Part Number: 30001534


No.	Description	Qty
43	10 Inch Saw Chain	1



SPARE PARTS / BAR AND CHAIN ASSEMBLY
CHAIN OIL TANK


Part Number: 20058354

No.	Description	Qty
34	Chain Oil Tank	1


CHAIN OIL CAP


Part Number: 20058356

No.	Description	Qty
35	Oil Cap	1


SPROCKET COVER

Part Number: 20058348

No.	Description	Qty
19	Sprocket Cover	1




SPARE PARTS / FILTER AND ACCESSORIES

AIR FILTER / FOAM

Part Number: 20058398


No.	Description	Qty
78	Air Filter / Foam	1



AIR FILTER HOUSING ASSEMBLY

Part Number: 20085776


No.	Description	Qty
79	Air Filter Housing Cover	1
76	Air Filter Housing Base	1
77	Screw M5x45	2



FUEL FILTER ASSEMBLY


Part Number: TBD00000

No.	Description	Qty
87	Balancer	1
88	Air Tube	1
89	Fuel Tube	1
90	Return Tube	1
91	Retainer Fuel Tube	1
92	Snap Ring	1
93	Fuel Filter	1





ASSEMBLY PARTS LIST



ASSEMBLY PARTS LIST

No.	Description	Qty
1	Screw M5x12	3
2	Pull Cord Sheath	1
3	Starter Cover	1
4	Starter Assembly	1
5	Starter Pull Cord	1
6	Start Handle	1
7	Coil Spring	1
8	Start Pulley	1
9	Start Spring	1
10	Ratchet Wheel	1
11	Plate Washer	1
12	Self-Tapping Screw ST4.8x16	1
13	Start Reel	1
14	Washer 8	1
15	Oil-Seal 12x22x7	1
16	Crankcase RH	1
17	Gasket \ Crankcase	1
18	Bearing 6001	2
19	Crank Shaft Assembly	1
20	Key 3x3.5x10	1
21	Bearing 6001 8x11x11	1
22	Circlip \ Piston Pin	2
23	Piston Pin	1
24	Piston	1
25	Piston Ring	2
26	Gasket \ Cylinder	1
27	Cylinder	1
28	Screw M5x20	4
29	Spark Plug	1
30	Self-Tapping Screw ST4.2x8	2
31	Air Deflector	1
32	Top Housing	1
33	Self-Tapping Screw ST4.8x16	1
34	Wire	1
35	Spark Plug Cover	1
36	Igniter	1
37	Screw M5x20	2
38	Pin Ø5x10	2
39	Crankcase LH	1


No.	Description	Qty
40	Screw M5x25	3
41	Oil-Seal 12x22x7	1
42	Magneto Rotor	1
43	Flange Nut M8x1	1
44	Flat Washer	2
45	Clutch Assembly	1
46	Elastic Washer M8	2
47	Bolt / Clutch	2
48	Pin Ø4x10	2
49	Fan Cover	1
50	Screw M5x20	4
51	Passive Disk	1
52	Circlip 35	1
53	Bearing 6202	1
54	Circlip 15	1
55	Clutch Drum Housing	1
56	Screw M6x20	4
57	Rubber	1
58	Clamp RH	1
59	Clamp LH	1
60	Screw M5x25	2
61	Screw M5x12	1
62	Screw M5x52	2
63	Muffler Heat Shield	
64	Muffler	1
65	Gasket \ Muffler	1
66	Gasket \ Muffler	1
67	Screw M4x12	2
68	Gasket	1
69	Admitting Pipe	1
70	Stamping	1
71	Screw M4x6	1
72	Screw M5x20	2
73	Gasket \ Carburetor	1
74	Carburetor	1
75	Air Box Assembly	1
76	Air Box Base	1
77	Screw M5x45	2
78	Air Filter	1

**ASSEMBLY PARTS LIST**

No.	Description	Qty
79	Air Box Cover	1
80	Fuel Tank Cover	1
81	Gasket Rubber	1
82	Anti-Falling Board	1
83	Fuel Tank	1
84	Rubber Bump	4
85	Fuel Tank Housing	1
86	Screw M5x25	4

No.	Description	Qty
87	Balancer	1
88	Air Tube	1
89	Fuel Tube	1
90	Return Tube	1
91	Retainer Fuel Tube	1
92	Snap Ring	1
93	Fuel Filter	1

ASSEMBLY PARTS LIST



ASSEMBLY PARTS LIST

No.	Description	Qty
1	Cord Holder	1
2	Sleeve 26	1
3	Clamp	1
4	Nut M5	1
5	Screw M5x22	1
6	Harness Clamp Assembly	1
7	Straight Shaft Assembly	1
8	Aluminum Tubing	1
9	Rubber	6
10	Driver Shaft	1
11	Cutting Attachment	1
12	Tension Screw	1
13	E Ring 5	1
14	Tension Block	1
15	Double End Stud M6x30	1
16	Sprocket 3/8	1
17	Plate Washer 6	1
18	Screw M6x14	1
19	Sprocket Cover	1
20	Nut M6	1
21	Screw M5x12	4
22	Gear Box Cover	1
23	Screw M4x10	2
24	Oil Pump	1
25	Oil Tube	1
26	Gear Box	1
27	Shaft Circlips 10	1
28	Hole Circlip 26	1
29	Bearing 6000-2Z	2
30	Transmission Gear	1
31	Screw M5x25	1
32	Screw M5x12	1
33	Screw M5x12	3
34	Chain Oil Tank	1
35	Chain Oil Cap	1
36	Chain Oil Nozzle	1

No.	Description	Qty
37	Bearing 627	1
38	Transmission Gear	1
39	Output Shaft	1
40	Oil Pump Worm Gear	1
41	Bearing 6001	1
42	Bearing Spacer	1
43	Saw Chain	1
44	Guide Bar	1
45	Front Handle	1
46	Nut M5	2
47	Handle Base	1
48	Clamp	1
49	Screw M5x28	2
50	Lock Washer 5	2
51	Plate Washer $\Phi 5 \times \Phi 12 \times 1.5$	2
52	Plate Washer $\Phi 5 \times 11 \times 2$	1
53	Plate Washer $\Phi 5 \times \Phi 12 \times 1.5$	1
54	Self-Tapping Screw ST4.8x19	2
55	Nut M5	4
56	Plastic Handle / LH	1
57	Spring / Trigger	1
58	Wire Cable A	1
59	Wire Cable B	1
60	Wire Tube	1
61	Throttle Cable Assembly	1
62	Plastic Handle / RH	1
63	Screw M5x14	2
64	Self-Tapping Screw ST3.5x9.5	2
65	Self-Tapping Screw ST4.2x10	2
66	Screw M5x14	1
67	Trigger	1
68	Switch	1
69	Lock Trigger	1
70	Spring / Trigger	1
71	Rear Handle	1

PRORUN regularly improves our products, and you may find slight differences between your machine and descriptions contained within this parts list. Modifications can be made to the machine without notice and without the obligation to update the operator's manuals, provided that the essential safety and functional characteristic remain unaltered. Contact PRORUN Customer Service with any questions and current specifications.