



1. Remove the old sink strainer. Apply plumber's putty around the top of the sink drain hole. Position the strainer body in the sink opening and press down to secure it into position.
2. From beneath the sink, slip the rubber and paper washers over the strainer body and position the drain cup over it. Thread the lock nut onto the strainer body and tighten it with a wrench.
3. Slide the slip nut onto the flange tailpiece. Place the poly washer on top of the tailpiece and position it under the sink strainer. Tighten the slip nut with a wrench, but do not over tighten it.