
#### **TOOLS REQUIRED**



#### Allen Wrench

(Included)



#### Phillips Screwdriver

(Not Included)



2 - Persons Recommended

#### **ASSEMBLY RATING**



EASY --- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

**VERSION # 19-09-03** 



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?  Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time!  Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

## PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.





#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

## ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

## **END TABLE**



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



#### **PARTS**





Table Top



#2)1pc



**Table Top Base** 





Right Panel





Left Panel

#5)2pcs




Side Panel

#6 2pcs



Glass

#7)1pc



Base

#8 1pc




Adapter 12V

## **END TABLE**



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



### **HAR**DWRE





Bolt Ø5/16" x 1-1/2"



(#B) 24pcs



Lock Washer Ø5/16"





Flat Washer Ø5/16"





Allen Wrench





Line Card

1


Part #1 x 1pc

Part #2 x1pc

Hardware #A x4pcs

Hardware#B x4pcs

Hardware#C x4pcs



2

Part #3 x2pcs


Part # x2pcs

Part #5 x2pcs

Hardware #A x8pcs

Hardware#B x8pcs


Hardware#C x8pcs



Align side panels to the top base (#1), then secure by using bolts (#A) with washers (#B,C).


3

Hardware#A x6pcs
Hardware#B x6pcs
Hardware#C x6pcs



4

Part #6 x 2pcs



Align glasses (#6) to the side panels.

