


## INSTRUCTION

# Adjustable 4 Rail Panel System




Installation video




## Parts

Adjustable Track × 1




**Check all pieces before installation.**  
Please contact GoDear Design directly if your product is missing items or parts.

## Prepare Tools



## Remark

**Screw Suggestion**




## Installation


**Push against Screw Marker where you want your track to start from**

**Step 1** - Mark the screws position with provided screw marker

### Wall Mount





### Ceiling Mount




**Step 2** - Install the Brackets ( Wall Mount or Ceiling Mount )




### Wall Mount




### Ceiling Mount



**Step 3** - Attach the Mounting Brackets to the Track



**DO NOT over extend the track as it may cause to separate completely.**




**DO NOT put the Track upon the Brackets.**

**Step 4 - Sliding Panel**




1




Measure the size you want

2




Cut out the length of Panel

3




Insert the panel

4




Insert the slice

5




6




4 bumper pads on each bottom rail recommended

**Step 5 - Attach the Panels**

Before attaching the panels , put the anti fray clips on the leftmost and the rightmost panels.  
Attach fabric panels on the pre-installed rails of the track with durable velcro.  
Starting from the end guide rails which recommended.



**Step 6 - Attach the 2 wands to the leading and ending guide rails**



**Tips**

Best 45 degree , use wand to open and close fabric panels with ease.

