


MANUAL INSTRUCTION

Corner Storage Cabinet

CB301BK01A-FY

CB301WH01A-FY



We offer a diverse range of products to meet the needs of customers.

Indoor Furniture

We are a professional furniture provider with top-notch factories and outstanding designs, Our mission is to provide consumers with new lifestyles. By collecting consumer feedback, we constantly improve our products and create more choices for consumers.

If you want to create your space,

We are an ideal choice.

————— Always. —————



All the Storage Cabinet
have passed strict
quality inspections
before deliver. Read
this manual carefully
to ensure proper usage.



WARNING

Ensure that all parts
and hardware are
available before
beginning assembly.








NOTICE

1. Children are not allowed to operate.
2. Do not pull the door vigorously to prevent the storage cabinet from tipping over.
3. Please attach the storage cabinet to the wall with an anti-tip device after installation is complete.
4. When using the storage cabinet for the first time, please keep it in a ventilated environment to allow the smell to fully evaporate.
5. When placing the partitions, please make sure the nails are firmly installed to prevent the partitions from falling off.
6. If any parts are missing, broken, damaged or worn, discontinue use of the product until repairs are made and/or factory replacement parts are installed.
7. Do not use this product in a manner inconsistent with the manufacturer's instructions, as this may void the product warranty.
8. If accessories are missing, please contact customer service for communication in time, we provide 7x24 hours after-sales service.
9. Do not use any attachments or accessories other than the original factory attachments and accessories.
10. Do not alter this equipment. Any alteration will create a safety hazard.

WARNING

1. Follow each step carefully to ensure the proper assembly of this product.
2. Two people are recommended for ease in the assembly of this product.
3. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
4. A Phillips head screwdriver is required for the assembly of this product .
5. Power tools should not be used to assemble this product .

I TOOLS REQUIRED



2 Persons Assembly















Up to 30 Minutes For Assembly










When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size.



PARTS



PARTS




HARDWARE


① $\Phi 15 \times 9.5\text{mm}$  34+2 PCS	② $\Phi 6.5 \times 35\text{mm}$  34+2 PCS	③ $\Phi 8 \times 30\text{mm}$  46+2 PCS	④ $\Phi 6.3 \times 50\text{mm}$  6+1 PCS
⑤ M4 X 36mm  1 PCS	⑥ $\Phi 3 \times 14\text{mm}$  4+1 PCS	⑦ $\Phi 3 \times 12\text{mm}$  8+1 PCS	⑧ $\Phi 5 \times 16\text{mm}$  4+1 PCS
⑨ $\Phi 4 \times 25\text{mm}$  16+1 PCS	⑩ 144 X 24 X 1.4mm  8 PCS	⑪ $\Phi 4 \times 12\text{mm}$  40+2 PCS	⑫ 96 X 20 X 18mm  2 PCS
⑬  4 PCS	⑭  4 PCS	⑮ $\Phi 4 \times 18\text{mm}$  8+1 PCS	⑯  2 SET

Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.








I PRODUCT ASSEMBLY



I PRODUCT ASSEMBLY


1


PART	NO.	QTY.	TOO.
	②	2	
	⑥	2	
	⑨	2	
	⑫	1	



I PRODUCT ASSEMBLY

2

PART	NO.	QTY.	TOO.
	①	4	
	②	2	
	③	4	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK



I PRODUCT ASSEMBLY

3


PART	NO.	QTY.	TOO.
	①	4	
	②	4	
	③	4	




I PRODUCT ASSEMBLY

4


PART	NO.	QTY.	TOO.
	①	4	
	②	4	
	③	6	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK



PRODUCT ASSEMBLY

5


PART	NO.	QTY.
	④	3
	⑤	1



I PRODUCT ASSEMBLY

6


PART	NO.	QTY.
	③	6



I PRODUCT ASSEMBLY

7


PART	NO.	QTY.	TOO.
	9	6	




I PRODUCT ASSEMBLY

8


PART	NO.	QTY.	TOO.
	①	4	
	②	4	
	③	4	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK




I PRODUCT ASSEMBLY

9

PART	NO.	QTY.	TOO.
	①	2	
	②	2	
	③	2	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


I PRODUCT ASSEMBLY

10

PART	NO.	QTY.	TOO.
	①	2	
	②	2	
	③	2	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


I PRODUCT ASSEMBLY

11


PART	NO.	QTY.	TOO.
	①	2	
	②	2	
	③	2	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK



I PRODUCT ASSEMBLY


12


PART	NO.	QTY.
	④	3
	⑤	1



I PRODUCT ASSEMBLY

13



PART	NO.	QTY.	TOO.
	⑥	2	
	⑨	2	
	⑫	1	




I PRODUCT ASSEMBLY

14

PART	NO.	QTY.	TOO.
	①	2	
	②	6	
	③	2	
	⑩	2	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK




I PRODUCT ASSEMBLY

15

PART	NO.	QTY.	TOO.
	①	4	
	③	4	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

PRODUCT ASSEMBLY


16


PART	NO.	QTY.	TOO.
	①	2	
	②	2	
	③	4	
	⑤	1	



I PRODUCT ASSEMBLY


17


PART	NO.	QTY.	TOO.
	9	6	



I PRODUCT ASSEMBLY

18


PART	NO.	QTY.	TOO.
	②	4	




I PRODUCT ASSEMBLY

19

PART	NO.	QTY.	TOO.
	①	4	
	③	4	



Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


I PRODUCT ASSEMBLY

20

PART	NO.	QTY.	TOO.
	7	8	
	13	4	
	14	4	
	15	8	



X2




X2

I PRODUCT ASSEMBLY

21


PART	NO.	QTY.	TOO.
	10	8	
	11	40	



I PRODUCT ASSEMBLY

22


PART	NO.	QTY.
	④	4



F plate can be installed at this end, according to customer needs.


Step 1

Select the desired height and put it in



Step 2

Aim the board gaps down



I PRODUCT ASSEMBLY

23





PART	NO.	QTY.
	16	2

We have included a set of tipping restraint hardware for this unit. You must install this hardware to prevent accidents or injuries that can result from the unit falling. When properly installed, this restraint can provide protection against the unexpected tipping of the unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your unit.

NOTE: The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware may be required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.




Install the tipping restraint hardware



I HELP CENTER


Question about your product? We're here to help. Visit us at:



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

We Stand Behind the Quality of Their Furniture

If you have any issues with your item please let us know! We will always do our best to come up with a solution that you will be happy with.

Please get in touch with our customer service team before returning the product.

And pls do not throw the original box(es) if you have not finished assembling or confirmed no quality issues.

Length of return period:

Items can be returned within 30 days of purchase.

In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:

1. Your item has a manufacturing defect in its materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after photos are sent.
2. Your item has been damaged in transit. For example, glass is broken or wicker is damaged. We will send you a prepaid shipping label after photos are sent.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after photos are sent of the wrong SKU numbers on the outer box(es).
4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

* However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:

1. You don't like the product(s) after receiving the box(es).
2. You no longer need the product(s) but you have received the box(es).
3. You buy the product(s) by mistake but you have received the box(es).
4. Order/Shipment cancellation failed and you have received the box(es).

Return Request

In order to get a full refund as described in this return policy, all items must be: (1) In a brand new/unused condition, please provide photos before and after packaging. (2) When returning, all accessories and parts are firmly packed in all original packaging.

If your return does not meet the requirements, you may not get a full refund.

When will I be refunded?

The refund is released once the goods have been returned to our warehouse.

What if the product is damaged/defective outside of the valid return period?

We want you to be a happy customer. Please reach out to us by email and we will come up with a solution to make sure you are satisfied.