


Assembly Instructions

ITEM NO. N717P352068
DINING SET

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the PARTS LIST and/or HARDWARE LIST shown below.

Caution: Please read the instructions thoroughly before assembly.







1. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not over tighten screws or bolts until the assembly is completed.
3. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.




Assembly Instructions

ITEM NO. N717P352068
DINING SET


PARTS LIST

NO.	COMPONENT	SKETCH	QTY.
A	SEAT CUSHION		2 PCS
B	BACK FRAME LEG		2 PCS
C	SHORT SIDE STRETCHER		4 PCS
D	LONG SIDE STRETCHER		2 PCS
E	FRONT LEG (RIGHT)		2 PCS
F	FRONT LEG (LEFT)		2 PCS

HARDWARE LIST

NO.	COMPONENT	SKETCH	QTY.
1	FLAT WASHER 5/16" x 19 x 1MM DIA.		16 PCS
2	SPRING WASHER 5/16" DIA.		16 PCS
3	BOLT M8 x 50MM		16 PCS
4	WOOD SCREW #8 x 45MM		12 PCS
5	ALLEN WRENCH M4		1 PC


ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)




Assembly Instructions

ITEM NO. N717P352068
DINING SET


STEP 1



STEP 2








STEP 3





Assembly Instructions


ITEM NO. N717P352068
DINING SET

PARTS LIST

NO.	COMPONENT	SKETCH	QTY.
A	TABLE TOP		1 PC
B	FRAME LEG (LEFT)		1 PC
C	FRAME LEG (RIGHT)		1 PC
D	SUPPORT ROD		2 PCS
E	STRETCHER		1 PC

HARDWARE LIST


NO.	COMPONENT	SKETCH	QTY.
1	FLAT WASHER 5/16" x 19 x 1MM DIA.		6 PCS
2	SPRING WASHER 5/16" DIA.		6 PCS
3	BOLT M8x 40MM		6 PCS
4	WOOD SCREW #8 x 45MM		6 PCS
5	ALLEN WRENCH M4		1 PC
	TIP KIT (2 SET)		2 PCS
			4 PCS
			2 PCS
			2 PCS




Assembly Instructions

ITEM NO. N717P352068
DINING SET

STEP 1




STEP 2




Assembly Instructions

ITEM NO. N717P352068
DINING SET

STEP 3



STEP 4



Assembly Instructions

ITEM NO. N717P352068
DINING SET

