


TOOLS REQUIRED




Allen Wrench

(Included)



2 - People Recommended



ASSEMBLY RATING



EASY --- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 22-01-14



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.




Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CORNER SOFA





- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

















Loveseat Frame

Chaise Longue Frame

Right Arm

Left Arm











Arm Cushion

Loveseat Frame Back

Chaise Longue Back











Chaise Seat Cushion (Compress)

Loveseat Seat Cushion (Compress)
















Pillow (Compress)

Chaise Seat Cushion
Cloth Sleeve


Loveseat Seat Cushion
Cloth Sleeve

CORNER SOFA





- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.



PARTS





Back Frame Cloth Sleeve





Leg

HARDWARE





Bolt Ø8 x 18mm







Bolt Ø8 x 80mm





Bolt Ø8 x 60mm





Flat Washer





Bolt Ø8 x 50mm





Mut







Allen Wrench


Carton	Disignation		Part	Hardware
	Loveseat Frame	#1		
	Arm Cushion	#5	x 2	
	Loveseat Frame Back	#6		
	Loveseat Seat Cushion (Compress)	#9	x 2	
	Back Cushion (Compress)	#10	x 2	
	Loveseat Seat Cushion Cloth Sleeve	#12		
	Chaise Seat Cushion Cloth Sleeve	#13	x 2	
	Back Frame Cloth Sleeve	#14		
	Chaise Longue Frame	#2		#A x 16pcs
	Right Arm	#3		#B x 14pcs
	Left Arm	#4		#C x 2pcs #D x 1pc
	Chaise Longue Back	#7		#E x 18pcs
	Chaise Seat Cushion (Compress)	#8		#F x 1pc
	Back Cushion (Compress)	#10		#G x 1pc
	Pillow (Compress)	#11	X2	
	Leg	#15	x 8	


Remove parts from hidden compartments under the loveseat frame (#1) and chaise longue frame (#2).






Part #15 x 8pcs
Hardware #A x16pcs
Hardware #G x1pc









Part #3 x1pc
Part #4 x1pc
Hardware #0 x6pcs


1. Align right arm (#3) to loveseat frame (#1) or the chaise longue frame (#2) and secure using bolts (#C) with washers (#E).


2. Align left arm (#4) to loveseat frame (#1) or the chaise longue frame (#2) and secure using bolts (#B,C) with washers (#E).



5
Part #5 x2pcs







8


Part #8 x1pc


Part #9 x2pcs

Cut the chaise and loveseat cushions (#8,9) so that they may expand.


Once the cushions have swelled up, insert into chaise and loveseat cloth sleeves (#12,13). Zip the sleeves up to close.

The compressed sponge has swelled up






Put a cloth cover on it.




Put a cloth cover on it.

9








10


Cut the cushion and pillow (#10,11) so that they may expand. Once the cushions have swelled up, pat evenly to shape.

Pat around evenly plump




The compressed sponge has swelled up

Pat around evenly plump




The compressed sponge has swelled up

11



12



OR

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

