


Cabinet

Assembly Instructions - Please keep for future reference



Dimensions

Width-67.7inch

Depth-13.8inch

Height-35.4inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.

4



















Assembly Instructions





Il y a 2 boîtes de ce produit

BOX-1: N721P192849


There are 2 boxes of this product

			
885x335x15mm	398x311x15mm	398x335x15mm	398x95x15mm
① x 1	② x 2	③ x 2	④ x 4
			
885x335x15mm	885x335x15mm	885x335x15mm	860x335x15mm
⑤ x 1	⑥ x 1	⑦ x 1	⑧ x 1
			
860x95x15mm	340x311x15mm	860x335x15mm	869x351x3mm
⑨ x 2	⑩ x 1	⑪ x 1	⑫ x 1
			
860x80x30mm	786x408x3mm	1719x335x15mm	410x418x15mm
⑬ x 1	⑭ x 2	⑮ x 1	⑯ x 2

BOX-1: N721P192849

			
410x435x15mm	390x300x5mm		
⑪ x 2	⑱ x 2		













BOX-2: WF314697

	Stovepipe X1
---	---------------------



Components-Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>(A)</p>  <p>Cam Bolt x 70+3</p>	<p>(B)</p>  <p>Cam Lock x 70+3</p>	<p>(C)</p>  <p>8*30mm Dowel x 36+2</p>	<p>(D)</p>  <p>Glass clips x 8</p>
<p>(E)</p>  <p>Back panel buckle x 24+2</p>	<p>(F)</p>  <p>Hinge x 4</p>	<p>(G)</p>  <p>Hinge x 4</p>	<p>(H)</p>  <p>3.5*14mm Screw x 48+3</p>
<p>(J)</p>  <p>felt x 12+2</p>	<p>(K)</p>  <p>Anti dumping x 2 set</p>	<p>(L)</p>  <p>Light Belt x 1</p>	<p>(M)</p>  <p>Screwdriver x 1</p>



1.



A*70



2.



B*8





C*4



Ø 8 x 30 mm

3.



B*8





C*4



Ø 8 x 30 mm

4.



B*8





C*4



Ø 8 x 30 mm

5.



B*8





C*4



Ø 8 x 30 mm



6.



B*4



7.



B*2




C*4



Ø 8 x 30 mm


8.



B*2



9.




C*4



Ø 8 x 30 mm


10.




B*8



11.



12.




C*4



Ø 8 x 30 mm





13.



B*12





14.



J*12



15.



B*10




C*8



Ø 8 x 30 mm



16.



E*24



17.x2



H*16



Ø 3.5 x 14 mm


G*4



F*4



18.




H*16



Ø 3.5 x 14 mm

19.




H*16




Ø 3.5 x 14 mm

20.



- ① Install the Stovepipe according to the Stovepipe instructions
- ② Place the Stovepipe in the middle of the cabinet

21.





D*8



22.

Please pass the light bar L through the holes on the back plate 14 and clamp them on the No. 18 glass respectively, and then tighten the glass clamp and fix the glass according to the diagram

Veuillez passer la barre lumineuse L à travers les trous de la plaque arrière 14 et les fixer respectivement sur le verre n° 18, puis serrer la pince à verre et fixer le verre selon le schéma




Please use a screwdriver to screw the bottom of the white shaft to fix the glass

S'il vous plaît visser le verre fixe au bas de l'arbre rotatif blanc avec un tournevis


L*1




23.



K*2




24.



Cabinet

Assembly Instructions - Please keep for future reference



Dimensions

Width-21.7inch

Depth-13.8inch

Height-66.9inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING

In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.


4



















Assembly Instructions

There is a protective film,
please tear it off.



No. 17 acrylic has a protective
film on both sides, please
remove it



Assembly Instructions

			
518x335x15mm	518x80x15mm	799x335x15mm	799x335x15mm
① x 1	② x 1	③ x 1	④ x 1
			
550x80x15mm	793x264x3mm	550x335x15mm	518x310x15mm
⑤ x 1	⑥ x 2	⑦ x 1	⑧ x 1
			
518x334x15mm	518x80x15mm	885x335x15mm	885x335x15mm
⑨ x 1	⑩ x 1	⑪ x 1	⑫ x 1
			
800x264x3mm	510x295x5mm	730x80x15mm	730x250x15mm
⑬ x 2	⑭ x 2	⑮ x 1	⑯ x 1















Assembly Instructions

 <p>714x258x4mm</p>	 <p>548x466.5x15mm</p>		
<p>17 x 1</p>	<p>18 x 1</p>		


Components-Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

(A)  Cam Bolt x 32+2	(B)  Cam Lock x 32+2	(C)  8*30mm Dowel x 26+2	(D)  3.5*14mm Screw x 30+2
(E)  6*12mm Screw x 8+1	(F)  Glass clamp x 8+1	(G)  felt x 6+2	(H)  Hinge x 5
(J)  Backboard buckle x 16+1	(K)  Screwdriver x 1	(L)  Anti dumping x 2 set	(M)  Light Belt x 1
(N)  Perfect Fit x 4+2	(P)  5*40mm Screw x 4+1		

1.





A*32



F*8



2.



B*4





C*2



∅ 8 x 30 mm

3.



B*4





C*2



∅ 8 x 30 mm

4.



B*4




C*2




Ø8 x 30 mm

5.



6.



B*2



C*6






Ø 8 x 30 mm

P*4



Ø 5 x 40 mm

7.



B*8





C*6



Ø 8 x 30 mm

8.



B*6





C*4





Ø 8 x 30 mm





9.



G*6



10.



N*4



B*4




C*4




Ø 8 x 30 mm

11.




Please put the strip light through the holes on the same side as No. 6 and No. 13 on the back panel, stick the top side of the No. 4 plate (to prevent obstruction of the glass), and press the bottom under the No. 7 board



M*1




J*16



M

12.




Please use a screwdriver to screw the bottom of the white shaft to fix the glass

13.

No. 17 acrylic has a protective film on both sides, please remove it

The top 17 is level with the 15 and 16 boards



Note that the distance between the lower edge of plate size 17 and plate size 15 and 16 is 16 mm

E*8



Ø6 x 12 mm

H*5









D*10



Ø3.5 x 14 mm



14.





D*20





Ø3.5 x 14 mm

15.




16.



DECORATIVE INSERT ELECTRIC FIREPLACE

OWNER'S MANUAL



Model: IF-1834W



CONSUMER SAFETY INFORMATION

- Read this manual before installing and operating this appliance
- Failure to follow these instructions may result in electric shock, fire property, or personal injury
- Do not store or use gasoline or other flammable liquids in vicinity of this appliance.

IMPORTANT SAFETY INFORMATION!



WARNING



- **Read all instructions before using this heater!**
- This heater is hot **when in use**. To avoid burns, **DO NOT** let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep **combustible materials**, such as furniture, pillows, bedding, papers, clothes, and curtains at least **3 feet (0.9m)** from the front of the heater, and **keep them away from the sides and rear**.
- **Extreme caution** is necessary when any heater is used by or near children or invalids and whenever the heater is left **operating and unattended**.
- **DO NOT** operate any heater with a **damaged cord or plug** or after the **heater malfunctions**, has been **dropped** or **damaged in any manner**. Discard heater, or return to authorized service facility for examination and /or repair.
- **DO NOT** run power cord under carpeting. **DO NOT** cover power cord with throw rugs, runners, or similar coverings. **DO NOT** route power cord under furniture or appliances. Arrange power cord away from **traffic area**, and where it will not be tripped over.




WARNING



- **Connect to properly grounded outlets ONLY.**
- **DO NOT** insert or allow foreign objects to **enter any ventilation or exhaust openings**, as this may cause **electric shock** or **fire**, or **damage the heater**.
- To prevent a possible fire, **DO NOT** block air intakes or exhaust in any manner. Doing so could cause a fire. **DO NOT** use on soft surfaces, like a bed, where openings may become blocked.
- A heater has **hot and arcing or sparking parts inside**. **DO NOT** use it in areas where **gasoline, paint, or flammable liquids** are used or stored.
- **Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.**
- **ALWAYS** plug heaters directly into a wall outlet/receptacle. **Never use with an extension cord or relocatable power tap (outlet/power strip).**
- **DO NOT** place the heater near a bed because objects such as pillows or blankets can fall off the bed and be ignited by the heater.
- **NEVER** use this heater in **bathrooms, laundry rooms**, or any other location where the heater could fall into a **bathtub or pool, become damp or come in contact with water**.
- **AVOID FIRE!** Regularly inspect all air vents to make sure they are free from dust, lint, or other Blockage. **Unplug the unit** and clean with a **vacuum ONLY**. **DO NOT** rinse or get wet.

- **ALWAYS** mount to wall bracket before use. DO NOT set on the floor, or other surface, to use.
- **NEVER** use a wall mount bracket from another manufacturer.
- This product is **not intended** to be a **primary heat source**. It is for **supplemental heat only**.
- **INDOOR use only! NEVER** use this heater **outdoors!** Doing so may result in **electric shock!**
- **Risk of electric shock! DO NOT OPEN!** No user-serviceable parts inside!
- **ALWAYS** turn this heater off before unplugging it from the outlet.
- **ALWAYS disconnect** this unit from the **power** supply **before** performing any assembly or cleaning, or before relocating the electric fireplace.
- **NEVER** leave this heater unattended. **ALWAYS** unplug this heater when not in use.
- **ALWAYS** store this heater in a dry location. **NEVER** use the fireplace if it has become wet.
- **NEVER** plug this heater into an outlet that is **old, cracked,** or has any **loose wires or connections**. Plugging this heater into a faulty outlet could result in **electric arcing** within the outlet that could cause the **outlet to overheat or catch fire**.
- **ALWAYS** check your heater cord and plug connections with **each use!**
 - i) **MAKE SURE** the plug fits tight in the outlet! Faulty wall outlet connections or loose plugs can cause the outlet to overheat.
 - ii) **Heaters draw more current** than small appliances. **Overheating** may occur even if it has not occurred with the use of other appliances.
 - iii) During use **check frequently** to see if the **plug outlet or face plate is HOT!**
 - iv) If the outlet or face plate is **HOT, discontinue use immediately** and have a qualified electrician inspect and/or replace the faulty outlets.

- The power cord supplied with the heater has a plug with two flat blades (live and neutral) and one round pin (ground). If a 3-slot receptacle is not available, an adapter **MUST** be used. The adapter **MUST** be **properly grounded** to the outlet box (see figure at right). (Note: Adapter NOT INCLUDED.)



- **SAVE THESE INSTRUCTIONS!**

PREPARATION









This product includes a **GLASS panel!** Always use **extreme caution** when handling **glass**. Failure to do so could result in **personal injury or property damage**.

Remove all parts and hardware from the carton and place them on a clean, soft, dry surface. Parts and assembly steps are grounded for wall-hanging or recessing use. Check the parts list to make sure nothing is missing. Dispose of packaging materials properly. Please recycle whenever

possible. You will need the following tools (not included): Phillips screwdriver; stud finder; level; tape measure; electric drill; 1/4" wood drill bit, hammer.

PARTS & HARDWARE


No.	Parts	Qty.
A	 <div>Electric Fireplace</div>	1
B	 <div>M4x8mm Screw</div>	3
C	 <div>Crystal stone</div>	1PK
D	 <div>Remote Control</div>	2
E	 <div>Instruction</div>	1
F	 <div>Metal</div>	1





ALWAYS KEEP THESE PARTS OUT OF REACH OF CHILDREN.LEAVE NO PLACE
 WHERE CHILDREN CAN FIND THEM.FAILURE TO DO SO COULD CAUSE A CHOKING HAZARD.




ENSURE the fireplace is unplugged before assembly, installation, cleaning or relocating. Failure to do so could result in electric shock, fire, or personal injury.




A: Remove the 6 white screws as shown in the picture, remove the glass and place into the crystal stone.



B: Return the glass to its original position and fix the 6 white screws.



C: Remove the 3 screws shown in the figure, install with the metal and then fix it in place.



D: Push the fireplace into the mantel, and then fix the fireplace to the mantel with three screws from the back.


WARNING

TURN OFF THE APPLIANCE COMPLETELY AND LET COOL BEFORE SERVICING. ONLY A QUALIFIED SERVICE PERSON SHOULD SERVICE AND REPAIR THIS ELECTRIC APPLIANCE.



Read and understand this entire owner's manual, including all safety information before plugging in or using this product. Failure to do so could result in electric shock, fire, serious injury, or death.

Control panel Operation



NEVER dispose of batteries in **fire**. Failure to observe this precaution **may result in an explosion**. Dispose of batteries at your local hazardous material processing center.

CARE AND MAINTENANCE

Cleaning



ALWAYS turn the heater **OFF** and **unplug the power cord from the outlet** before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in **electric shock, fire, or personal injury**.



NEVER immerse in water or spray with water. Doing so could result in electric shock, fire, or personal injury.

Metal:

- Buff using a soft cloth, slightly dampened with a citrus oil-based product.
- **DO NOT** use brass polish or household cleaners as these products will damage the metal trim.

Glass:

- Use a good quality glass cleaner and dry thoroughly with a paper towel or lint-free cloth.
- **NEVER** use abrasive cleansers, liquid sprays, or any cleaner that could scratch the surface.

Vents:

- Use a vacuum or duster to remove dust and dirt from the heater and vent areas.
- Clean the exterior of the fireplace with a slightly damp cloth or duster.

Maintenance



Risk of electric shock! DO NOT OPEN! No user-serviceable parts inside!



ALWAYS turn the heater **OFF** and **unplug the power cord from the outlet** before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in **electric shock, fire, or personal injury**.

Electrical and Moving Parts:

- The fan motors are lubricated at the factory and will not require lubrication.
- Electrical components are integrated in the fireplace and are not serviceable by the consumer.

Storage:

- Store heater in a clean dry place when not in use.



WARNING! No other servicing should be performed by the consumer. Do not attempt to service the unit yourself.

LotusLantern APP Manual

1. Software Overview

1.1 Overview

LotusLantern is a mobile APP to control LED strip by both Apple and Android phones.

The traditional control ways like infrared, 433MHz, 2.4GHz and others old wired ways will be replaced by mobile phone control way with convenient, powerful and scalable features.

Through this mobile APP , you can not only control the color, brightness and color temperature of the LED strips but also set up all kinds of fancy flash mode ; Also this APP can change the light of the LED strip according to the rhythm of the music. This APP can set and control several LED strips through Bluetooth and the operation is very simple, easy to learn and easy to use.

1.2 Features

- Adjust color LED strips with 60,000 colors to change color and brightness and adjust monochrome LED strips to change brightness and color temperature
- Play music or turn on a sound playback device, you can let the light change the color and brightness with the rhythm of music, the music rhythm beautiful
- Inside multiple setting mode for color change and control LED strips without mobile
- Long distance control with omni-directional antenna, and many-to-many group control mode
- Once the connection is successful, connect automatically next time

1.3 Performance

LotusLantern APP is easy for use as well as great compatible for all kinds of smart phones; After the actual test of hundreds of mobile phones verification, the compatibility is above 95% of mobile phones in the market. APP is small and convenient, it consumes less system resources, so the requirements of the mobile configuration are low. Control delay is small, the operation feel good, light control is smooth with people's visual sense.

2. Operating Environment

This APP program requires phones of system above Android 4.3 and iOS 8.0. Mobile phone configuration is not limited.

3. Instructions

Note: Android version and iOS version download and use the same method, here in the Android version as an example.

3.1 APP Download


Scan the QR code

iOS and Android systems can download the "LotusLantern" APP by scanning the QR code. Open the browser or other tools with "Scan QR code" function, scan the "LotusLantern" QR code as below:




3.2 App Operation


(1) Click on the LotusLantern APP icon, enter the APP page:



(2) After entering the APP interface, if Bluetooth is not enabled, "an application wants to enable the Bluetooth function of this device." Click [Allow]



(3) switch to color and brightness interface:




(4) click to show the lamp list, view lamp list:




(5) Click to RGB manual adjustment view:




(6) switch to the mode interface:




(7) switch to the music rhythm interface:




(8) Switch to the online music interface:



(9) Switch to the microphone rhythm interface:



(10) Switch to the schedule interface:



(11) Switch to the modify pin sequence interface:

