

INSTALLATION INSTRUCTIONS

1. Remove handle.
2. Unscrew nut and pull out stem.
3. Lift out old seats and springs out of valve body.
4. Insert new springs and seats in valve body.
5. Insert new stem and tighten nut securely.

Important! For knob handle faucets, both stops must point toward spout for clockwise closing. For lever handle faucets, both stops point toward the right.

INSTRUCCIONES DE INSTALACIÓN

1. Quite el mando.
2. Desenroscar la tuerca y sacar el eje.
3. Saque los asientos y resortes viejos y fuera del cuerpo de la válvula.
4. Insertar los resortes y asientos nuevos en el cuerpo de la válvula.
5. Inserte el eje y apriete la tuerca de seguridad.

¡Importante! Para llaves de perilla, ambos obstructores deben apuntar hacia el surtidor para que cierren siguiendo a las manecillas del reloj. Para llaves de palanca, ambos obstructores deben apuntar hacia la derecha.

