## ASSEMBLY INSTRUCTIONS

## ITEM NO. FB3028CST-SC-4PK



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

PARTS LIST					
NO.	DIAGRAM	PART NAME	Q'Ty		
1		Chair Back	1PC x4		
2	$\bigcirc$	Seat Frame With Cushion	1PC x4		
3		Leg	2PCS x4		

## HARDWARE LIST

NO.	DIAGRAM	PART NAME	Q'Ty
A		Bolt Ø1/4" x 1-1/2"	2PCS x4
В		Bolt Ø1/4" x 2-3/8"	4PCS x4
С		BoltØ1/4" x 3"	4PCS x4
D	$\bigcirc$	Lock Washer Ø1/4"	10PCS x4
E		Flat Washer Ø1/4" x 19mm	10PCS x4
F		Allen key 4mm	1PC x4









**ASSEMBLY TIPS:** 

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.









