



HIDE IT WITH STYLE

Box Contents


EC18029

SCREEN FRAME




A

Post (3)
3" x 3" x 48"



B

Board (20)
 $\frac{5}{8}$ " x 4 $\frac{1}{2}$ " x 44"




C

Stake (2)
1 $\frac{1}{4}$ " x 1" x 16"


The wooden stakes are pressure treated to be more durable when installed in the ground.

ACCENT PIECES



D


Dowel (6)



E

Post Cap (3)

SCREWS



F


#10 2 $\frac{3}{8}$ " Wood Screw (4)
Bag (F)



G

#8 2 $\frac{1}{2}$ " Wood Screw (16)
Bag (G)

SPACER



H

Wood Spacer (2)