

INSTALLATION INSTRUCTIONS

VOLT® LOW VOLTAGE LANDSCAPE LIGHTING

VOLT® Adjustable Outdoor Brass Spot Light

ITEM: LAL-SPKIT3

1-813-978-3700 • Mon-Fri 8am-8pm • Sat-Sun 10am - 6pm (EST)

**IMPORTANT: PLEASE READ BEFORE INSTALLATION**

This fixture is intended for installation in accordance with local codes and the National Electric Code (NEC). Failure to adhere to these codes and instructions may result in serious injury, property damage and void the warranty.

These instructions do not intend to cover all variations in installation, operation maintenance or mounting situations.

1. Make sure that the power is turned OFF before installing or servicing this fixture.
2. Warning: this fixture is not intended to be installed within 10 feet [3 meters] of a pool, spa or fountain.
3. This fixture is intended to be used only with a power supply (transformer) rated maximum of 300 watts (25 AMPS) at 15 volts.
4. Underground Low Energy Cable must not be buried over 6" (15.2 cm) in order to connect to the main low voltage cable.
5. Wiring connections must be made with wire connectors that are suitable for outdoor use.
6. Position the wire connector so that it is located within 6 inches (15.2 cm) from a building structure, luminaire, or fitting.

IMPORTANT SAFETY INFORMATION**LIT FIXTURE IS HOT!**

WARNING – To reduce the risk of FIRE OR INJURY TO PERSONS.

1. Turn off/unplug and allow to cool before reducing lamp.
2. Lamp gets HOT quickly!
3. Do not touch the hot lens, guard or cowl.
4. Keep lamp away from materials that may burn.
5. Do not touch lamp at any time.
6. Use a soft cloth.
7. Oil from skin may damage lamp.
8. Do not operate the fixture with a damaged or missing lens or shield.


SAVE THESE INSTRUCTIONS

PACKAGE CONTENTS


- A. (1) Fixture Body
- B. (1) MR8 Bulb

- C. (1) Stake


PRODUCT DIMENSIONS




1 REMOVE GLARE GUARD



Loosen the screw and remove the glare guard from the fixture body.

2 REMOVE THE LENS


Unscrew the lens and remove it from the fixture body.

3 INSTALL MR8 BULB

Insert MR8 bulb with correct wattage and type marked on fixture label.


CAUTION: Do not exceed maximum wattage marked on luminaire label.

NOTE: DO NOT touch MR8 bulb with bare hands. Use soft cloth to handle the bulb.

4 INSTALL THE LENS


Screw the lens top back onto the fixture body and hand tighten until snug.

5 INSTALL THE GLARE GUARD



Place the glare guard back onto the fixture body and secure with previously removed screw. Hand tighten until snug.


6 INSTALL STAKE



Determine your desired location for mounting the transformer. Hammer the stake into the ground until flange of stake is flush to grade. To avoid damage to the stake, place a board on top of the stake while hammering.


Note: If the ground is hard and the stake is difficult to install, make a crosscut in the ground using a flat shovel.

7 INSTALL FIXTURE BODY TO STAKE




Pass supply wires through the center of the stake and thread the fixture body onto the stake. Hand tighten until snug. Clear away area in ground and lay supply wires into wireway slots.

8 WIRE CONNECTIONS



Strip two leads from fixture supply wires. Using two UL listed wire connectors (not provided), connect leads from fixture supply wires to main supply cable leads.

9 ADJUST DIRECTIONS



Loosen the thumb screw at the joint and adjust the luminaire to your desired direction. Always tighten the thumb screw after adjustment.

INSTALL/REPLACE MR8 BULB

Please refer Step 1 - Step 3 to expose the MR8 bulb and replace it with correct wattage and type marked on fixture label. Then reinstall the lens and glare guard.

IMPORTANT: MR8 bulb must be protected from moisture and dust at all times. Always re-install the lens and glare guard when moved.



1-813-978-3700 • Mon-Fri 8am-8pm • Sat-Sun 10am - 6pm (EST)

Specifications and product details subject to change without notice.
© Copyright 2024, VOLT® Lighting, Lutz FL USA 33549 • All rights reserved.
customersupport@voltlighting.com • www.voltlighting.com