


welcoming • sophisticated • inspiring

24-IN Vanity with Top

(24-IN W x 18-IN D x 35-IN H)




Date Purchased _____

Questions, problems, missing parts?

Before returning to your retailer,
call our customer service department at
1-855-571-1044 9 a.m. - 5 p.m., EST, Monday-Friday.
www.greentouchhome.com


Greentouch



MODEL NUMBER	DESCRIPTION
1192VA-24-201	24" White Finish Vanity with Top
1192VA-24-242	24" Light Gray Finish Vanity with Top
1192VA-24-245	24" Coffee Oak Finish Vanity with Top

PACKAGE CONTENTS

PART	DESCRIPTION	QUANTITY
A	Vanity	1
B	Top	1
C	Left Door (preassembled to Vanity (A))	1
D	Right Door (preassembled to Vanity (A))	1
E	Shelf	1
F	Cubby	2



HARDWARE CONTENTS (NOT SHOWN ACTUAL SIZE)

AA



Touch Up Pen
Qty. 1

SAFETY INSTRUCTIONS

Please read and understand this entire manual before attempting to assemble, operate or install the product.

WARNING

- Some steps are more easily handled with 2 adults.

CAUTION

- Use care when assembling the vanity; take your time and follow the assembly instructions closely.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Installation Time: 25-30 minutes (24 hours for adhesive to dry).

Tools Required for Installation (not included): Phillips screwdriver, utility knife or scissors, adhesive, power drill with drill bit, measuring tape, level.

INSTALLATION INSTRUCTIONS

Note: Clean area where the Vanity Cabinet (A) will be permanently located prior to beginning installation, ensuring the Vanity Cabinet (A) will not interfere with any water supply and drain lines once mounted.

1. With two people, carefully place Vanity Cabinet (A) against the wall in its final location. Find and mark locations of wall studs behind the permanent location of Vanity Cabinet (A).
From inside Vanity Cabinet (A), drill hole through vanity mounting area and into wall studs. Using mounting hardware (not included) appropriate for your installation site, secure Vanity Cabinet (A) to wall stud. If possible, secure Vanity Cabinet (A) to two wall studs for increased stability.

Note: Use preassembled levelers on legs of Vanity Cabinet (A) to level the item. Twisting the levelers counterclockwise will increase the height of Vanity Cabinet (A), twisting them clockwise will decrease it.





WARNING

Vanity Cabinet (A) **MUST** be secured to wall studs.

2. Locate Top (B) and set aside.


TIP: It may be easier to install faucet and drain assemblies (neither included) to Top (B) at this time. Install them per the manufacturers' instructions to complete the installation.

With the help of another adult, apply a bead of silicone adhesive (not included) to the top edge of the Vanity Cabinet (A) and back side of Top (B) where it rests against the wall. Lower Top (B) onto Vanity Cabinet (A). Wipe any excess silicone from both the outer and inner edges of where the Top (B) rests on the Vanity Cabinet (A). Allow silicone to dry for 24 hours before use.



INSTALLATION INSTRUCTIONS

3. Place shelf (E) on top of shelf pins.




4. If you need to adjust the doors, do so in the following manner.

To adjust door up or down, loosen screws (a) on both hinges, adjust door, and retighten screws.


To adjust door left or right, turn screws (b) on both hinges, in or out.

To adjust door in or out, loosen screws (c) on both hinges, adjust door, and retighten screws.




INSTALLATION INSTRUCTIONS

5. Locate the cubby (F), while holding a door in one hand place the holes in the cubby on to the pins located on the inside of the door, then slide down into place. If holes don't line up first time then take the cubby of the inside of the door and attempt to replace again. Repeat with opposite side.



6. To remove drawers preassembled in Vanity Cabinet (A). Fully extend drawers, locate plastic levers on metal glide tracks at left and right sides of drawer box, push on plastic levers on both sides at the same time, to disengage drawer box from the glides, Then gently lift the drawer up to remove it from the glide tracks.



INSTALLATION INSTRUCTIONS


7. To reinstall drawer into Vanity Cabinet (A), fully extend metal glide tracks. Gently lower and slide drawer box into rear glide catch. Next lower drawer box down to completely rest on extended glides. Then, push plastic levers to lock the drawer box in place.

Note: To Adjust the drawer box height, Spin the adjustment wheel to the left to raise the drawer box or spin the adjustment wheel to the right to lower the drawer box. You can adjust the left and right side glide heights independently in order to find the drawers best alignment position.

CAUTION

DO NOT force drawer or damage to glide may occur. If drawer does not slide in with ease, remove and try again from the start.

Assembly is now complete. Install desired faucet and drain assemblies (neither included) if not already done at step 2. Per the manufacturers' instructions to complete the installation.



CARE AND MAINTENANCE

- Dust the vanity regularly with a soft, non-lint producing cloth or household dusting product.
- You can clean the vanity with a gentle, non-abrasive household cleaner.
- Make sure to dry the wood immediately with a soft cloth or towel.
- Tips for using touch-up pen (AA): For scratches, stroke in direction of scratch; for worn areas, stroke in direction of wood grain. Rub off excess colorant promptly with a soft cloth.

IMPORTANT



- **DO NOT** use products to clean the top that contain acetone, lemon, vinegar or other acids as these may cause damage to the Top surface.
- To avoid scratching or damaging the Top finish do not use abrasive cleaners.

WARRANTY

The manufacturer warrants this item against defects in materials and workmanship for a period of one (1) year from the date of original retail purchase. This warranty applies only to the original purchaser. This warranty does not apply to any damage on the product by accident, misuse, or modified, improper installation or by affixing accessories not produced by the manufacturer. The manufacturer will not be held liable for damages caused from cleaners or soaps that etch or stain the stone top. The manufacturer is not accountable whatsoever for product installation during the warranty period. There is no further expressed warranty. The manufacturer shall not be legally responsible for incidental, consequential or special damages arising at or in connection with product use or performance except as may otherwise be accorded by law. The manufacturer disclaims any and all implied warranties.

REPLACEMENT PARTS FOR 1192VA-24-201

For replacement parts, call our customer service department at 1-855-571-1044, 9 a.m. - 5 p.m., EST, Monday - Friday.





PART	DESCRIPTION	PART #
B	Top	1196GC-24
C	Left Door	1192VA-24-201-001/002
D	Right Door	
E	Shelf	1192VA-24-201-003
F	Cubby	1192VA-24-201-004
G	Drawer Front	1192VA-24-201-005

PART	DESCRIPTION	PART #
AA	Touch-Up Pen	OF-0010
BB	Door Pull	PU-1192-BN
CC	Hinge	PU17-1192-EU-SC
DD	Drawer Glide	PUDTC-12x3-HANDLE
EE	Shelf Pin	PU17-SP-002
FF	Leveler	T-1007

REPLACEMENT PARTS FOR 1192VA-24-242

For replacement parts, call our customer service department at 1-855-571-1044, 9 a.m. - 5 p.m., EST, Monday - Friday.





PART	DESCRIPTION	PART #
B	Top	1196GC-24
C	Left Door	1192VA-24-242-001/002
D	Right Door	
E	Shelf	1192VA-24-242-003
F	Cubby	1192VA-24-242-004
G	Drawer Front	1192VA-24-242-005

PART	DESCRIPTION	PART #
AA	Touch-Up Pen	OF-0120R
BB	Door Pull	PU-1192-BN
CC	Hinge	PU17-1192-EU-SC
DD	Drawer Glide	PUDTC-12x3-HANDLE
EE	Shelf Pin	PU17-SP-002
FF	Leveler	T-1007

REPLACEMENT PARTS FOR 1192VA-24-245

For replacement parts, call our customer service department at 1-855-571-1044, 9 a.m. - 5 p.m., EST, Monday - Friday.



PART	DESCRIPTION	PART #
B	Top	1196GC-24
C	Left Door	1192VA-24-245-001/002
D	Right Door	
E	Shelf	1192VA-24-245-003
F	Cubby	1192VA-24-245-004
G	Drawer Front	1192VA-24-245-005

PART	DESCRIPTION	PART #
AA	Touch-Up Pen	OX-0940S
BB	Door Pull	PU-1192-BN
CC	Hinge	PU17-1192-EU-SC
DD	Drawer Glide	PUDTC-12x3-HANDLE
EE	Shelf Pin	PU17-SP-002
FF	Leveler	T-1007