
Bosch Product Dimensions

Bosch Dishwashers

Models: SHE Models



Width	24" to 24 1/4" (23 5/8" with décor strips removed)
Height	34" to 35" (36" with Custom Toe-Kick *Always use included metal toe-kick behind custom toe-kick
Depth	24"
Upper Clearance	Leave 1/8" to 1/4" of space between the countertop and the dishwasher
CUE madala da n	ot accept custom panels.

