

Guide Book

- The R/C controls the forward/backward and left/right movements, with remote control having priority.
- Music
- Volume adjustment
- Power display
- Forward and backward
- High and low speed
- Wireless connection

















If you have any question, please contact at L843485741@outlook.com directly.



 **WARNING:** The toy is to be assembled by an adult.
In unassembled state contain potentially hazardous sharp points, sharp edges and small part,so please keep out of baby' s reach

 **Warning:** Not to be used in traffic.

Parts List:(Name and Quantity)

											
A	B	C	D	E	F	G	H	I	J	K	L
car body	seat	backrest	door	steering wheel	front axle	rear axle	front wheel	rear wheel	driving motor	windshield	rear bracket
1	1	1	2	1	1	1	2	2	2	1	1
											
M	N	O	P	Q	R	S	T	U	V	W	X
middle shock absorber module	two sides shock absorber module	flatiron	front spring	bracket	front fender	rear fender	wheel cover	front bumper	rearview mirror	rearview mirror holder	searchlight holder(L/R)
1	2	1	2	2	2	2	4	1	2	2	2
											
Y	Z	a	b	c	d	e	f	Y	Z	a	b
1	1	1	1	38	7	5	2	1	1	1	1




Product Specifications:

Name	Specification	Name	Specification
Battery	24V	Speed	2.5-3.5 km/h
Suitable age	37-95 months	Charge/Use time	charge 8-12h, use 1h
Loading capacity	30kg	Charger	24V
Product size	102×63×65cm	Remote control	AAA1.5V

The above parameters are selected by the customer, and the specific parameters shall be subject to the actual sample.

Function



Button function	
① High/low speed	⑥ Stop/playswitch
② Mode switch	⑦ Charging hole
③ Power/light control switch	⑧ Music switch/Volume -
④ Screen	⑨ Music switch/Volume +
⑤ Horn sound	⑩ Forward/backward

Remote control function and explanation

Do not shift forward/backward button when car is driving, or will damage the motor.
Remote control can be used normally when battery is assembled.
Remote control should be used under adults’ supervision.
Remote control is preferred to manual control.



How to adjust R/C frequency:
Long press forward and backward button for 3 seconds, and the speed indicator flashes. Then turn on the power, the speed indicator goes to long bright which means the connection is successful. If the speed indicator no response, means the connection failed. Replace the batteries and retry.

Remote control battery operation

Take off the battery cover. Put two AAA1.5V remote control battery in with right polarity.
New and used batteries cannot be used together.
Do not insert batteries into wrong polarity, or will be short-circuited.
Non-rechargeable batteries cannot be recharged. Exhausted batteries should be replaced by adults.
The exhausted battery must be handled and operated properly by adults only. Do not be played by children.

Installation Order Diagram

1. Bracket, front fender, rear fender and front bumper decoration assembly

Insert the bracket(Q), front fender(R) and rear fender(S) into the reserved place on the car step by step, then use 8pcs screw(c) to tighten the bracket(Q). At last, insert the front bumper(U) into the reserved place like picture.



2. Front axle and front spring assembly

First, put the flatiron on the front axle(F). Put 1pcs front spring(P) to each side of square tube. Then insert the front axle(F) into the hole of square tube, add 1pcs washer(d) and use spanner(f) to tighten the nut(e). The same way for the other side. Direction rod should be passed through the hole of front axle(F), then add 1pcs washer(d) and use spanner(f) to tighten the nut(e).




3. Front wheel assembly

Add 1pc washer(d), 1pc front wheel(H), 1pc washer(d) step by step, use spanner(f) to tighten the nut(e). Finally put the wheel cover(T) on. The same way for the other side.



4. Middle shock absorber module, two sides shock absorber module, rear axle and rear bracket assembly

Insert middle shock absorber module(M), two sides shock absorber module(N) and rear bracket(L) into the reserved place on the car step by step, then use 22pcs screw(c) to tighten. At last, insert rear axle(G) into the holes reserved place on the module.



5. Motor assembly

Add 1pc motor(J), 1pc rear wheel(I), 1pcs washer(d) step by step, use spanner(f) to tighten the nut(e). The same way for the other side.




6. Door and rearview mirror holder assembly Steering wheel assembly

Insert the door(D) into the reserved place on the car, then insert the rearview mirror holder(W) into the reserved place on the car and door. Use 2pcs screw(c) to tighten. The same way for the other side. Unscrew the steering wheel(E), insert steering wheel(E) into the direction rod, use screw and nut to tighten.



7. Battery line and motor line connection

Connect battery line and motor line like picture.



8. Seat and backrest assembly

Insert the backrest(C) into the reserved place on the car first, use 2pcs screw(c) to tighten, then insert the seat(B) into the reserved place on the car, use 2pcs screw (c) to tighten.



9. Windshield, rearview mirror, searchlight holder, searchlight assembly

Insert the windshield(K), rearview mirror(V), searchlight holder(X) into the reserved place on the car. Then insert the searchlight(Y) into the searchlight holder(X).



Warnings

For children's safety, please read these carefully.

Assembly and adjustment must be done by adults, keep children away. Keep children under 36 months away from small parts. A safety belt is a must when children are playing. Do not be close to fire. An adult must teach how to play with it and never leave children alone while playing. Do not stand up or play when children are stepping on the foot pedal. The battery must be charged by adults only. Please charge it first before use. Keep children away from plastic bag, or suffocation may occur. Only use spare parts provided by manufacturer. The charger is not a toy for playing. The maximum loading capacity is 30KG. Do not overload. Suitable age: 37-95 months.

Safety use

Do not play in the street, road, slope or ditch. Do not change the line or add electric device to the car. Play the car in the dry area, not wet. Keep away from fire, or may damage the line. One rider at a time only. Do not overload. Maximum capacity is 30KG. Turn power off if no use. If long time no use, unplug battery line. Check battery, charger and other spare parts regularly. If any problem, please fix it before playing.

Charging notification

For the first use, please charge 8-12 hours, or will damage the battery. Plug charger DC line into charge hole first, then plug charger into socket. The car cannot be used while it charging. Every time it is charging, do not charge more than 20 hours. It is normal that charger and battery warm (under 60°) during charging. Do not charge if plug is wet, or will occur short-circuited. Only use charger provided by manufacturer, or will damage charger and battery or occur short-circuited. If long time no use, please charge 1 time per month at least.

Charging steps are as follows:

Step 1: The charging hole is on the multi-functional board.
Step 2: Put the charger plug into the plug hole.
Step 3: Connect the charger to the power socket.



Warning: Car must be charged by adults only. Car is useless during charging

Maintenance and Service

Check battery, charger and other spare parts regularly. If any problem, please fix it before playing.

- Use lubricating oil to care iron parts. Keep car away from fire and sunshine. Park it on the even place, not reversal or gradient.
- Park it indoor and cover it with waterproof cloth.
- Keep car away from fire, like stove or heater, or plastic may melt.

Keep away from flammable things, or a fire accident may occur.

- Charge it after use and must be done by adults only. If long time no use, please charge it 1 time per month, in order to maintain battery.
- Clean the vehicle with a dry cloth only. Do not use chemical solvent to wipe plastic parts. Do not wash it with water or play it when raining or snowing. Water will damage motor, electric system or battery.
- Please turn power off after each use.
- Only use charger provided by manufacturer.
- Do not change car's structure or electric line. A check job request some skills or under specialist's guidance.