


KOBALT®



ITEM #4882353

24-IN STORY STICK

MODEL #SCM-24

Español p. 6

KOBALT® and logo design are trademarks or registered trademarks of LF, LLC. All rights reserved.

ATTACH YOUR RECEIPT HERE

Serial Number _____ Purchase Date _____




Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 888-3KOBALT (888-356-2258), 8 a.m - 8 p.m., EST, Monday - Sunday. You could also contact us at partsplus@lowes.com.

TABLE OF CONTENTS

Package Contents.....	3
Safety Instructions	4
Preparation	4
Assembly Instruction.....	4
Warranty.....	5

PACKAGE CONTENTS



PART	DESCRIPTION	QUANTITY
A	Track section	1
B	Sliding tabs	4
C	Twisting knob of end stop	1
D	End stop	1

SAFETY INSTRUCTIONS

Keep out of reach of children.


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 5 minutes

ASSEMBLY INSTRUCTION


- 1.) Twist counter-clockwise to release the knob of the end stop.



- 2.) Assemble the end stop per figure 2.



- 3.) Install the end stop and sliding tabs by inserting the bolts into the rail on the track section.




WARRANTY

For 1 year from the date of purchase, the product is warranted for the original purchaser to be free from defects in material and workmanship. This guarantee does not cover damage due to abuse, normal wear, improper maintenance, neglect, unauthorized repair/alteration, or expendable parts and accessories expected to become unusable after a reasonable period of use.

If you think your product meets the above guarantee criteria, please return it to the place of purchase with valid proof of purchase and the defective product will be repaired or replaced at no charge. This guarantee gives you specific legal rights, and you may also have other rights that vary from state to state.

KOBALT®



ARTÍCULO #4882353

GUÍA DE 60,96 CM

MODELO #SCM-24

KOBALT® y el diseño del logotipo son marcas comerciales o marcas registradas de LF, LLC. Todos los derechos reservados.

ADJUNTE SU RECIBO AQUÍ

Número de serie _____ Fecha de compra _____




¿Preguntas, problemas, piezas faltantes? Antes de volver a la tienda, llame a nuestro Departamento de Servicio al Cliente al 888-3KOBALT (888-356-2258), de lunes a domingo de 8 a.m. a 8 p.m., hora estándar del Este. También puede ponerse en contacto con nosotros en partsplus@lowes.com.

ÍNDICE

Contenido del paquete	8
Instrucciones de seguridad	9
Preparación	9
Instrucciones de ensamblaje	9
Garantía	10

CONTENIDO DEL PAQUETE



PIEZA	DESCRIPCIÓN	CANTIDAD
A	Sección del riel	1
B	Lengüetas corredizas	4
C	Perilla giratoria del tope para extremo	1
D	Tope para extremo	1

INSTRUCCIONES DE SEGURIDAD

Manténgase fuera del alcance de los niños.


PREPARACIÓN

Antes de comenzar a ensamblar el producto, asegúrese de tener todas las piezas. Compare las piezas con la lista del contenido del paquete. No intente ensamblar el producto si falta alguna pieza o si estas están dañadas.


Tiempo estimado de ensamblaje: 5 minutos

INSTRUCCIONES DE ENSAMBLAJE


- 1.) Gire en dirección contraria a las manecillas del reloj para liberar la perilla del tope para extremo.



- 2.) Ensamble el tope para extremo según lo muestra la figura 2.



- 3.) Instale el tope para extremo y las lengüetas corredizas insertando los pernos en el riel en la sección del riel.



GARANTÍA

Este producto tiene cobertura de garantía contra defectos en materiales y mano de obra por 1 año a partir de la fecha de compra para el comprador original. Esta garantía no cubre daños debidos al maltrato, desgaste normal, mantenimiento inadecuado, negligencia, reparaciones o alteraciones no autorizadas o piezas y accesorios prescindibles que se espera que resulten inutilizables después de un período de uso razonable.

Si cree que este producto cumple con la garantía mencionada anteriormente, devuelva el producto al lugar donde lo compró con un comprobante de compra válido y el producto defectuoso se reparará o reemplazará sin cargo. Esta garantía le otorga derechos legales específicos, pero también podría tener otros derechos que varían según el estado.

Impreso en China

