

Versión  
en español  
al dorso



**AMPLIFIED**  
indoor antenna

## QUICK START GUIDE

ANT1268E Insert 01

Check out setup videos at  
**[www.RCAAntennaHelp.com](http://www.RCAAntennaHelp.com)**

### 1 Use the RCA Signal Finder App to find the best location for your antenna.




In the Google Play or Apple App Stores, search for “RCA Signal Finder” and look for the icon shown here. Then download and install the App.

Launch the App and follow the directions there to find the best location and orientation for your antenna.

#### Antenna Placement Tips


- ✓ Avoid metal surfaces (like a metal stand).
- ✓ Move the antenna close to or in a window.
- ✓ Position the antenna as high as possible.

### 2 Connect the antenna to your TV.



**Note:** If your TV's antenna input is already connected to a satellite receiver, cable box, or digital converter, connect the antenna's coaxial cable to the antenna input jack on that device.

### 3 Plug in the antenna.



Insert the power adapter into the antenna's DC jack. Plug the other end into a wall outlet or power strip.

### 4 Adjust your antenna for best reception.

To start, extend the antenna's dipoles (rods) to their full length.

You might find that different channels require different antenna adjustments. If you're not receiving channels you normally receive, try the following adjustments in the order listed here:

- > Rotate the antenna's dipoles. Try them at different lengths.
- > Rotate the base of the antenna. (Don't forget to move it back to its original position for the other channels.)

### 5 Scan for channels on your TV.

Most TVs have a channel scan option in their menu system, many times in a SETUP or CHANNEL menu under ANTENNA.

For detailed instructions on performing a channel scan, see the owner's manual that came with your TV.

**Important:** You must perform a channel scan to receive any channels!

# STOP!

**DO NOT RETURN** this product to the store! Visit **[RCAAntennaHelp.com](http://RCAAntennaHelp.com)** for instructional and how-to videos.

English  
version on  
other side



**antena  
AMPLIFICADA  
para interiores**

## GUÍA DE INICIO RÁPIDO

Consulte los videos de configuración en  
**[www.RCAAntennaHelp.com](http://www.RCAAntennaHelp.com)**

### 1 Utilice la aplicación RCA Signal Finder para determinar la mejor ubicación para su antena.




En las tiendas Google Play o Apple App, busque "RCA Signal Finder" y el icono que aquí se muestra. Ahora descargue e instale la aplicación.

Abra la aplicación y siga las instrucciones para determinar la mejor ubicación y orientación para su antena.

#### Consejos para la ubicación de la antena


- ✓ Evite las superficies de metal (tal como un soporte de metal).
- ✓ Coloque la antena en una ventana o cerca de ella.
- ✓ Coloque la antena lo más alto posible.

### 2 Conecte la antena al TV.



**Aviso:** Si la entrada de la antena de su TV ya está conectada a un receptor de satélite, aparato de cable o convertidor digital, conecte el cable coaxial al conector de entrada de la antena en dicho dispositivo.

### 3 Enchufe la antena.



Inserte el adaptador de potencia en el conector de CC de la antena. Conecte el otro extremo a un tomacorriente de pared o extensión.

### 4 Ajuste su antena para obtener la mejor recepción.

Para comenzar, extienda los dipolos (barras) de la antena en toda su longitud.

Tal vez notará que diferentes canales podrían necesitar diferentes ajustes de antena. Si no recibe los canales que está acostumbrado ver, intente llevar a cabo los siguientes ajustes en el orden que aparecen a continuación:

- > Gire los dipolos de la antena. Pruébelos a diferentes longitudes.
- > Gire la base de la antena. (No olvide cambiarla nuevamente a su posición original para los demás canales.)

### 5 Busque canales en su TV.

La mayoría de televisores tienen una opción de búsqueda de canales en el menú del sistema, con frecuencia se encuentra en el menú de CONFIGURACIÓN o CANALES en la sección ANTENA.

Para obtener instrucciones detalladas sobre cómo llevar a cabo una búsqueda de canales, consulte el manual del propietario incluido con el TV.

**Importante:** ¡Debe realizar una búsqueda de canales para recibir los canales!

# ¡ALTO!

**NO DEVUELVA** este producto a la tienda. Visite **[RCAAntennaHelp.com](http://RCAAntennaHelp.com)** para videos de instrucciones y prácticos.