


For additional assistance or service please contact:

SPEAKMAN® Company 400 Anchor Mill Road New Castle, DE 19720



customerservice@speakman.com




92-S-2580-01


TOOLS AND SUPPLIES


Thread Seal Tape Hex Key Wrench (INCLUDED)
















 \triangle

0

0

0

SAFETY TIPS

Cover your drain to prevent loss of parts.


MAINTENANCE

Your new Shower Arm is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will dull the finish and void your warranty.

WARRANTY

Additional warranty information can be found at: www.speakman.com

S-2580 ROUGH IN DIAGRAM



Specifications:

Supply Inlet: 1/2" NPT MALE
Outlet: 1/2" NPT MALE

Note: Dimensions are subject to change without notice

The supply fittings behind the wall shall be properly secured and anchored to support the shower arm and any attachments added.