



Hearth Cushion

Fits up to 80" total across front of Hearth
Call 1-800-845-9236 if Hearth is longer than 80".

Made in USA

INSTALLATION INSTRUCTIONS

Model 6010/6020/6030

TOOLS NEEDED: Measuring Tape, Pencil, Straight Edge, Razor Knife, Rubbing Alcohol, Cloth, brush or vacuum cleaner

Step 1: Use brush or vacuum cleaner to remove any loose brick or mortar particles. Clean hearth and underside of Hearth Cushion with rubbing alcohol.

Step 2: Place LH & RH Corners on hearth. If Corners are too deep to fit on hearth, trim using Pad cutting instructions below. (Figure 2)

Step 3: Apply double sided attachment tape to LH & RH corners. Press firmly on tape and then remove liner. Hold LH corner tight against the front and side of hearth and press firmly on hearth. Repeat for RH corner. (Figure 2)

Step 4: Measure between LH and RH corners. Add $\frac{1}{8}$ " to measurement and mark line on Center Connector with pencil. Cut Center Connector to length using Pad cutting instructions. Place Center Connector on hearth and check fit. (Figure 2)

Step 5: Place double sided attachment tape on hearth between the LH & RH corners. Press firmly in place and remove liner. (Figure 2)

Step 6: Place left hand end of Center Connector next to LH Corner on hearth. Make sure Center Connector is lined up with Corner. Press Center Connector firmly against LH Corner and against front of hearth. Press Center Connector firmly into place on hearth next to corner. Make sure to keep Center Connector pressed against front of hearth and press it firmly into place along hearth. Be careful not to stretch Center Connector as you attach it to hearth. (Figure 3)

MATERIALS INCLUDED

ITEM	DESCRIPTION	QTY
A	Left Hand Corner	1
B	Right Hand Corner	1
C	Center Connector	1
D	Attachment Tape	1




Fig. 1




Fig. 2




Fig. 3

Pad Cutting Instructions.

- 1) Place Pad on top of shipping box or some other flat surface so that when you cut through Pad, the knife will not damage your floor or hearth below.
- 2) Lay straight edge on top of Pad and line it up with mark.
- 3) Using a sharp razor knife, hold it next to straight edge and cut through Pad using light to medium pressure. For best looking cut, make multiple passes along straight edge until you have cut through Pad. DO NOT try to cut through the Pad in one or two passes. Trying to cut pad in one pass may result in jagged cut.

Note: The Soft Seat Hearth Pad is made from a durable, non-toxic, flame retardant foam rubber. Clean with soap and water.

CUSTOMER SERVICE: KidKusion, Inc., PO Box 1686
Washington, NC 27889
Phone: 1-800-845-9236