

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble or install the product.

- Three people are need for assembly.

WARNING:

- KEEP ALL FLAME AND HEAT AWAY FROM THIS GAZEBO FABRIC.
- This gazebo meets the flammability requirements of CPAI-84 The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the gazebo fabric may render the flame-resistant properties ineffective.

CAUTION

- Do not leave outside during high winds, heavy rains or snow. If high winds, heavy rains or any snow occurs, remove canopy and Sidewall, clear snow load from roof, and check for damage before continued use.

CARE AND MAINTENANCE

- For cleaning, use a mild detergent solution, rinse with water, and allow to air dry. Do not use acetone, abrasive, or other special detergents as they would be harmful to the product's finish.
- Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

WARRANTY

1 YEAR WARRANTY FOR FRAME AND FABRIC.

- WHAT IS COVERED

We provide warranty to the original purchase for 1 year for frame and fabric from the date of purchase, and the fabric and frame will be replaced at no charge due to manufacturing defects.

- WHAT IS NOT COVERED

We do not reimburse for transportation costs. This warranty does not cover the damage caused by commercial use, acts of nature, fire, freezing, and abusive use. Discoloration or fading of the finish or fabrics as a result of chemicals or spills is not covered.

Contact the Customer Service Team at 1-866-439-9800.