

ASSEMBLY INSTRUCTIONS



ITEM #: C1854/C1855D-DTR RECTANGLE DINING TABLE

Reading struction carefully priorto assembly

Thank you for purchasing this quality product. Check carefully for small parts which may have come loose during shipment.

Remove all components from pack and place table top upside down on softsurface such as carpet or clothto prevent scratching the finish. Identify and count all parts as specified below. Do not tighten bolts until assembly is complete.


"PART LISTS"

STT	DESC	OUTLOOK	Q'TY
1	TABLE TOP		1pc
2	TABLE LEGS		4pcs

"HARDWARE LISTS"

STT	OUTLOOK	SIZE	Q'TY
A		5/16"x 2 1/4"BOLT	8pcs
B		5/16" SPRING WASHER	8pcs
C		5/16"x19mm LOCK WASHER	8pcs
D		4mm ALLEN WRENCH	1pc

STEP 1



FINAL

