

Unlock the window by lifting the lock handle up. Lift the operating handle and crank the sash to open.