


PORCH SWING

ASSEMBLY INSTRUCTION



If you have any questions, feel free to email us
at zzwservice@gmail.com

THANK YOU

Register and Get the Full Benefit

It's our way of saying thank you.







Register your product to enjoy a number of benefits:

- (1) 1-year warranty extension
- (2) 24/7 quicker service and product support
- (3) Chance to test new products for free
- (4) Get specific discount on shop items






Register Way: Send " your name + order ID " to zzwservice@gmail.com

Assembly Instruction


Parts List

A	B	C	D
			
Seat panel	Back panel	Left armrest	Right armrest
1 PC	1 PC	1 PC	1 PC
E	F		
			
Seat cushion	Back cushion		
1 PC	3 PCS		

Hardwares List

#1	#2	#3	#4
			
Screw M6*40 (mm)	Screw M6*55 (mm)	Allen key 4# (mm)	Big nut safety clasp
8 PCS	2 PCS	1 PC	6 PCS
#5			
			
2 PCS			


Assembly Instruction - Porch swing




STEP 1

A x1

B x1



1.1



1.2


Place A and B as shown in the figure;

A

Assembly Instruction - Porch swing

STEP 2

#1 x2




NOTE Do not tighten the screws completely. If fully tightened, it may cause difficulty in installing the step 3 of handrail assembly.

Assemble B with A using screw #1;

STEP 3

C x1




Place C as shown in the figure;

Assembly Instruction - Porch swing

STEP 4

#1 x3

#2 x1




DO NOT tighten screws completely until assembly is completed;

Assemble C with A and B using screw #1, screw #2;

STEP 5

D x1






Place D on A and B;

Assembly Instruction - Porch swing

STEP 6

#1 x3


#2 x1



DO NOT tighten screws completely until assembly is completed;

Assemble D with A and B using screw #1, screw #2;

STEP 7





Tighten all the screws completely;

Assembly Instruction - Porch swing

STEP 8

#4 x6

#5 x2



The nut safety buckles must be locked;
Regularly inspect the chain and the suspension
as a whole for safety hazards.





Suspend the swing chair with chains where needed as shown;
Adjust the length of the chain suspension as needed to adjust the tilt angle of the swing chair;

Assembly Instruction - Porch swing

STEP 9

E x1

F x3



The plastic tea table can be unfolded and retracted.

Place E and F as shown in the figure;