

PARTS & ASSEMBLY SHEET

Fixture Name: Payton 1157-M1L CH/AB

This fixture assembled PO:_____ Date:

Notice: Please review the parts listing and check for all parts before assembling the fixture. If any parts are missing or damaged, please note on this sheet and contact the place of purchase to arrange for replacement parts.

PARTS LIST		Company Name:		Co. Account #:		
		to be filled out by retailer				
Canopy 1ea D5"xH1"		Wire Connectors 3ea A4 Orange		Top Lo	00p D50 x 60mm	
ica bo xiii		Jea A4 Olalige		ica	D30 X 00111111	
Chain		Junction Box Screw		Spring	g Washer	
1ea 6ft x3.8mm		2ea 8/32" x 1"		1ea	@15 x 2mm	
Chain Connector 2ea @4.2X50mm		Canopy Loop with Collar 1ea @3/8 x 40mm x 5mr		Nippl	e @3/8 x 455mm	
2ea @4.2X30IIIII		169 62/0 x 4011111 x 31111	11	rea	@3/6 X 455111111	
Mounting Strap w/ ground screw		Hex Nut				
1ea 3/4"X4"	•	2ea @3/8 x 3mm				
Part Needed				_	Quantity_	
Part Needed	(missing, scratched, broken glass, bent, bad finish)					
Reason why Comments						


FIXTURE ASSEMBLY INSTRUCTIONS

Read and review installation instruction sheet before assembling the fixture.

Note: The wire cage and glass shade are already assembled on the fixture body.

1. Thread the Top Loop (J) onto the nipple of Fixture Body (M). Hand-tighten until snug.

1157-M1L CH/AB



For Customer Service, contact the place of purchase to arrange for replacement

PARTS & ASSEMBLY SHEET

Fixture Name: Payton 1157-M1L CH/AB


ASSEMBLING THE FIXTURE (Fig. 2)

- 2. Measure to determine the correct number of links needed for the proper hanging height. Use a pair of pliers to open one link of the Chain (K) then remove and discard the excess chain.
- 3. Use one Chain Connector (L) to attach one end of the chain to Top Loop (J) and close the chain connector.
- 4. Feed the fixture wires through the chain (every three links) and pull the wires until taut.
- 5. Slip Canopy Loop Collar (H) over the chain. Then do the same with Canopy (G).
- 6. To complete the installation, use the other chain connector and attach the other end of the chain to Canopy Loop (F) and close the chain connector.
- 7. Make sure the weight of the chandelier will be supported by the chain, not the electrical wire.
- * You may now install the fixture.

Note: Complete these remaining steps after the fixture is hung.

8. Install the light bulb (not provided) in accordance with the fixture's specifications.

(DO NOT EXCEED MAXIMUM WATTAGE RATING)





INSTALLATION INSTRUCTIONS

Fixture Name: Payton 1157-6/4/3P CH/AB

For Chandelier Light Fixture

WARNING! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

HANGING THE FIXTURE (Fig.1)

- 1. Carefully remove the new fixture from the carton and the yellow bag that holds all parts. Check that all parts are included as shown in the illustration and Parts List.
- 2. Shut off the power at the circuit breaker and remove the old fixture from the ceiling, including the old mounting strap.
- 3. Thread Nipple (C) into Canopy Loop (F) until snug.
- 4. Thread the other end of Nipple (C) with the canopy loop attached into Mounting Strap (D).
- 5. Place Lock Washer (B) over end of Nipple (C) which should protrude through Mounting Strap (D) and thread Hex Nuts (A) onto Nipple until tight.
- 6. Take this mounting strap assembly and mount to ceiling junction box with junction box Screws (E). Tighten the screws securely with a screw driver.
- 7. Unscrew Canopy Loop Collar (H) from the canopy loop. Take the canopy and pass over the canopy loop.

Approximately one half of the canopy loop exterior threads should be exposed. Adjust until desired height is reached. *The canopy loop collar should fit snugly on the canopy loop after the canopy is installed. Remove canopy and canopy lock collar.


- 8. Assemble the fixture and have an assistant or a secure support to hold the weight of the fixture while you complete the wiring connections.
- 9.Thread the fixture wires and ground wire of the assembled fixture through the canopy loop and nipple and into the outlet box.


CONNECTING THE WIRES (Fig 2)

- 10. Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED).
- 11. Ground wire connection: Connect the fixture ground wire to house ground wire, which usually has green or copper insulation, with the correct size of wire connector. If there is no house ground wire at ceiling junction box then attach fixture ground wire securely onto green grounding screw located on the mounting bar.

NOTE: Twist the wires together in the same direction that you twisted the wire connector onto the wires.

- 12. Tuck the wire connections into the Junction Box.
- 13. Raise Canopy (G) to the ceiling and secure in place by tightening the Canopy Loop Collar (H) into the Canopy Loop (F)
- 14. Install the light bulbs and glass shade as per the fixture assembly sheet.





YOUR INSTALLATION IS NOW COMPLETE. RETURN POWER TO THE JUNCTION BOX AND TEST THE FIXTURE.

For Customer Service, contact the place of purchase to arrange for replacement parts.