



1. Remove all components from the strainer body.
2. Apply a small amount of putty evenly around the top hole in the sink, approximately 1/2" from the opening.
3. Insert the basket strainer into the sink opening. Slide the rubber washer up to the sink. Thread and tighten the lock nut onto the washer.
4. Place the poly washer on the tailpiece extension. Connect the tailpiece to the strainer using the slip nut. Tighten it securely to the strainer. Test for leaks by running water.