




OIL-FILLED RADIATOR HEATER

OH12

PRODUCT USE GUIDE

INTRODUCTION

Thank you for choosing a heater. This owner's manual will provide you with valuable information necessary for the proper care and maintenance of your new product. Please take a few minutes to read it.

TABLE OF CONTENTS

SECTION 1

IMPORTANT ATTENTION	PAGES 3-4
---------------------	-----------

SECTION 2

SAFETY FEATURES	PAGES 5
IMPORTANT TIPS	PAGES 5
INSTRUCTION FOR ASSEMBLE	PAGES 6

SECTION 3

PRODUCT DIAGRAM	PAGES 7
INSTRUCTION FOR USE	PAGES 7

SECTION 4

STORAGE	PAGES 8
PRODUCT SPECIFICATIONE	PAGES 8

SECTION 5

MAINTENANCE & CLEANING	PAGES 8
WARNING	PAGES 9
TROUBLESHOOTING	PAGES 9

SECTION 6

WRANTY	PAGES 10
IN THE BOX	PAGES 10

IMPORTANT ATTENTION

When using this electric unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- (1). Read all instructions before using this heater.
- (2). CAUTION: Risk of Electric Shock. DO NOT open or try to repair the heater without technical guide.
- (3). This heater may get hot when in use. To avoid burns, DO NOT let bare skin touch hot surfaces. Please use handles when moving this heater. DO NOT place it against walls, furniture, curtains, etc.
- (4). Keep combustible materials, such as furniture, pillows, bedding, paper, clothes, and curtains at least 3ft from the front of the heater and keep them away from the sides, top, and rear. DO NOT place towels or other objects on the heater.
- (5). Extreme caution is necessary when any heater is used.
- (6). DO NOT operate any heater with a damaged cord or after the heater malfunctions, has been dropped or damaged in any manner. Please contact us first, our after-sales customer service will arrange return and exchange for you.
- (7). This heater is not intended for use in bathrooms, laundry areas, showers or swimming pools and similar locations. NEVER locate heater where it may fall into a bathtub or other water container. To protect against electrical hazards, DO NOT immerse in water or other liquids.
- (8). DO NOT touch the control panel or plug with a wet hand.
- (9). DO NOT run cord under carpeting. DO NOT cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- (10). DO NOT insert or allow foreign objects to enter any ven-tilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- (11). To prevent a possible fire, DO NOT block the air intakes or exhaust in any manner. DO NOT use on soft surfaces, like a bed, where openings may be blocked.

-
- (12). A heater has hot and arcing or sparking parts inside. DO NOT use in areas where gasoline, paint, explosive and/or ammable liquids are used or stored. Keep unit away from heated surfaces and open flames.
- (13). Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- (14). To avoid fire or shock hazard, plug the unit directly into a 110 - 120 V AC electrical outlet.
- (15). To disconnect heater, turn controls to OFF, then remove plug from outlet. Pull firmly on the plug, DO NOT unplug by pulling on the cord.
- (16). Always unplug the heater before moving or cleaning, or whenever the heater is not in use.
- (17). Use only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by unauthorized dealers may cause hazards.
- (18). Always use on a dry, level surface. Use on floor only.
- (19). DO NOT use outdoors.
- (20). WARNING: To reduce the risk of fire or electric shock, DO NOT use this unit with any solid-state speed control device.
- (21). DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user service-able parts.
- (22). Always use the product in an upright position.

SAFETY FEATURES

Overheat Safety Feature


This heater is equipped with an overheat safety feature. When the heater's internal components reach a certain temperature that could cause overheating and possible fire, the heater will automatically shut off.

- A thermal overload protector is built in to prevent overheating. When an "overheat" temperature is reached, the heater will automatically shut off. Operation can resume only when the user resets the unit.
- To reset the unit, unplug the heater, ensure the power is turned off, and wait 15 to 20 minutes for the unit to cool down.
- Follow INSTRUCTIONS FOR USE to return heater to operating mode.

IMPORTANT TIPS

IMPORTANT TIPS BEFORE USE	
WARNING & NOTICE	It is normal for the power cord to feel warm to the touch; however, a loose fit between the outlet and the plug may cause overheating of the plug. If this occurs, try inserting the plug into a different outlet. Contact a qualified electrician to inspect the original outlet for damage.
	When the heat funtion is used for the first time, a slight odor may be present. This is normal and should not occur again unless the heater is not used for an extended period of time.
	DO NOT cover heater at any time during operation, as there is risk of FIRE if heater is covered.

INSTRUCTION FOR ASSEMBLE




Remove the heater and all the accessories from the box.

- (1). Turn the heater upside down.
- (2). Slide the Base Feet on to the fins ends as shown in above image.
- (3). Turn the heater right side up, slide the right base feet on to the fins ends.
- (4). Check the stability of the heater by standing it on a smooth level surface.

WARNING

DO NOT open or refill/change oil fins. Oil fins are permanently sealed and DO NOT require refilling or oil changing. Attempting to open fins will damage the unit. This unit is filled with a non-toxic mineral oil.

PRODUCT DIAGRAM



INSTRUCTIONS FOR USE

- (1). Place the product on a firm, level surface.
- (2). Plug the unit directly into a 110 - 120V AC electrical outlet.
- (3). Turn the POWER SWITCH to the "ON" position.
- (4). Turn the THERMOSTAT CONTROL DIAL to "LOW".
- (5). For faster heat up or to increase heat output, turn the THERMOSTAT CONTROL DIAL clockwise to the "HIGH". The thermostat function controls the temperature output. To decrease the heat output, turn THERMOSTAT CONTROL DIAL counter clockwise.
- (6). Once the room reaches the desired temperature, slowly turn the THERMOSTAT CONTROL DIAL counter clockwise until you hear a "click". This sets the heater to cycle ON/OFF to maintain the desired heating temperature for energy efficiency.
- (7). It will normally require approximately 15 minutes to reach operating temperature.

STORAGE

- (1). Save the original box for off-season storage.
- (2). Clear the heater with a soft, damp cloth.
- (3). Remove the Base Feet.
- (4). Place the Radiator and Base Feet in the original box, and store in a cool and dry place.
- (5). Ensure the heater is covered to protect from the dust.

PRODUCT SPECIFICATION

Model No.	OH12
Item Name	OIL-FILLED RADIATOR HEATER
Rated Voltage	110 - 120V (60Hz) 5.9 Amps
Rated Power	700 W
2 Setting Thermostat Control	Low / High
Safety Protection	Overheat Protection

MAINTENANCE & CLEANING

- (1). Turn the POWER SWITCH to the “OFF” position.
- (2). Unplug the unit and let it cool completely.
- (3). To keep the heater clean, the outer shell may be cleaned with a soft, damp cloth. A mild detergent can be used if necessary.
- (4). After cleaning, dry the unit with a soft cloth.
- (5). Wait until the unit is completely dry before use.

WARNING

- DO NOT let liquid enter the heater.
- DO NOT use alcohol, gasoline, abrasive powders, furniture polish, or rough brushes to clean the heater. This may cause damage or deterioration to the surface of the heater.
- DO NOT immerse the heater in water.

TROUBLESHOOTING

If the heater will not operate, please check the following:

- (1). Check if the power cord is plugged into an electrical outlet. If not, plug in unit to appropriate outlet.
- (2). Ensure the POWER SWITCH is turned to “ON” position.
- (3). Make sure heater is placed on a flat solid surface.
- (4). Check for obstructions at the intake and exhaust vents.
- If obstructions are present, refer to the instructions for resetting your heater when the Overheat Protection System has been activated.
- If no obstructions are present, and your heater still does not operate normally, turn the POWER SWITCH to the “OFF” position, disconnect the power cord from the electrical outlet, and consult an authorized repair technician.


NOTICE	The product is equipped with an overheat safety feature protector which will switch off the heater in case of accidental over heating (ex. Obstruction of air intake and outlet grills, motor turning slowly or not at all).
--------	--

WARRANTY


After-sales Service Letter of Commitment:

All products purchased in our company are guaranteed to keep in good repair for 1 year. If quality problems happen in guarantee period, our company will maintain for free or provide replacement. Additionally, our company provides technical support and fittings for life. After-sales service isn't restricted by time and hear feedback idea of users and deal with them in time. If you are caught in some problems when using our products, welcome to contact us at any time.

IN THE BOX



Oil-filled Radiator Heater



Owner's Manual