

USER INSTRUCTION

Folding Stadium Seat



How To Use :



Remove reclining seat from the package and lay flat on a levelled surface/ground

01 To Use With Armrests



Press the middle of the stadium seat



Lift the backrest up



Comfortable armrest

02 How to fix it to the bench (Using straps)

If using on a backless bench, please open the strap under the seat and secure the strap to the seat



Flip and find the strap



Open the strap



Tie to the seat

03 To Use Without Armrests



Press the armrest on both sides



Lift the backrest up



Adjustable in multiple gears

How to convert the form without armrests to the form with armrests

01



02



FLIP THE CHAIR OVER


03



04



What to do if the backrest cannot be fixed/upright ?



Lay the chair flat. When there is a creaking sound and the chair Press the chair until it can't be pressed any further it indicates that the gear can be adjusted normally and the backrest can be fixed

04 How To Store And Carry



Press the backrest forward



Press the stand chair down and flat

Folding Stadium Seat (Lying flat effect)

