

# Plant Grow Floor Lamp Installation Instruction

Please read the instruction manual carefully before using.

Dear Customer,

Thank you for choosing this lamp! To save your time and effort, please try to light up the lamp before installation to ensure the sockets are working correctly. If you have any issue when you receive it, please contact us , we will reply your message in 30 mins. Thank you for your understanding.

- Customer Support Team


## Specification

Voltage	110-120V
Certification	Sockets are UL Listed
Warranty	2 Years

## Package List

Lamp pole	1
Floor Lamp Base	1
20W Grow Blub	1
Instructions	1
Metal Shade	1

## Installation



- 1.Remove the rubber ring from the tube.
- 2.Screw the round tubes one by one from the bottom to the top, and connect them accordingly, so that they can be assembled into a complete light pole.
- 2.After assembling the lamp pole, screw it to the base.
- 3.Connect the adjusting rod to the plug of the main rod and screw the adjusting rod to the main rod.
- 4.Slip the metal shade over the lamp base, tighten it with the head ring and screw on the grow bulb.
- 5.Unscrew here to adjust the up and down angle of the sunlamps.
- 6.Switch functions include: on/off function and timer function. Timer time is divided into: 4 hours, 8 hours and 12 hours.