




- Dimensions are approximate. Unit dimensions should be verified before installation.
- Installation must be done according to the manufacturer's instructions.