


Mixcept

for a lively home

ASSEMBLY INSTRUCTIONS BOOKCASE ITEM# AM180709




For services and questions, please send email to us : meandro@126.com


THANK YOU

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product .




- VI. Power tools should not be used to assemble this product .




- VII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment



Vertical
Via slots in the mounting
plate or via cam
adjustment

- VIII. Insert cam lock into panel tighter with a screwdriver;



 WARNING


Serious or fatal injuries can occur from furniture tip-over.

To help prevent furniture tip-over:


- 1/ It is recommended to use mounting hardware to secure furniture to the wall. This may reduce but not eliminate the risk of furniture tip-over.
- 2/ Do not allow children to climb on furniture.
- 3/ Keep remote controls, toys and other items that might attract children off from this product.
- 4/ Do not allow children to step on furniture.
- 5/ Unless specifically designed to accommodate , do not set televisions or other heavy objects on top of this product.


Caution:Do not allow door stay open when moving furniture.

Parts List



Hardware List



A		M8*30(mm)	Wooden dowel	40 pcs	
B		M6*32(mm)	Cam bolt	40 pcs	
C		Ø15*9.5mm	Cam lock	40 pcs	
D		M3.5*14mm	Screw	16 pcs	
E		Ø30	Sticker	40 pcs	
F		M3*12(mm)	Screw	54 pcs	
G			Handle	2 pcs	
H		Ø4x18mm	Handle Screw	2 pcs	
I		Ø26	Hinge	4 pcs	
J		Ø4x12	Screw	16 pcs	
k	k-1		nylon strap	1 pcs	
	k-2		Ø3*16	Screw	1 pcs
	k-3		Ø4*25	Screw	1 pcs
	k-4		plug	1 pcs	




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1




Step 2




Step 3




Step 4




Step 5








Step 6








Step 7






Step 8






Step 9




Step 10



Step 11




Step 12




Sequence 13 14 15 16 17 18

Step 13



Step 14



Final Assembly