

# How to repair a roof to stop leaks

## REPAIRING ROOF PROJECTIONS



1. Flashings pulling away from walls should be reset in roof cement.
2. With flashing in place, apply **roof cement** 2-3" above & below where the flashing meets wall
3. Embed **Universal Patching Fabric** into the cement. Spread additional roof cement over the entire repair area.
4. Repeat for bottom of flashing.



## REPAIRING CRACKS



1. Cover cracked and damaged area with **Roof Cement**.
2. Cut and place a strip of **Universal Patching Fabric** into the cement. Spread more roof cement over entire repair area and let cure.

## REPAIRING ROOF PROJECTIONS



1. Apply roof cement at base of projection. Spread the cement around the repair.
2. Embed **Universal Patching Fabric** into the cement directly over entire repair area.
3. Apply additional **roof cement** over fabric reinforcement to completely seal repair.



## REPAIRING BLISTERS



1. Cut an "X" in roofing material where blister is located. Peel back the flaps exposing the underlying surface. Allow area to dry.
2. Trowel **roof cement** into exposed area making sure to cover entire area. Push flaps back down to cover the underlying surface. Cover with additional roof cement.

