Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



Not for commercial use. For residential use only.



Prolonged exposure to rain may cause rusting which can stain floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



 Do not write on furniture without a padded barrier to protect the surface.



To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



• Stains may be removed with mild soap solution and damp cloth.




Keep away from sources of ignition.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look into the Carton for hardware packs and legs.

Dining Chair




<u>Parts List</u>

Label	Picture	Description	QTY
A	- <u></u>	Backrest	1
В	- <u>II</u>	Seat Panel	1
С		Front Leg	2

<u>Hardware</u>				
Label	Picture	Description	QTY	
1		Allen Wrench	1	
2		Bolt (M6*15MM)	3	
3		Bolt (M6*30MM)	4	
4		Washer (M6*14MM)	6	

Assembly Preparation

Before Beginning Assembly:





· Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-

Assembly Steps


<u>Overview</u>



This Dining Chair has multiple parts and may require up to 30 minutes to assemble.


To give you an overview of the Dining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise yourself with the parts and steps before assembly.

Step 1




Open the carton and place all the parts onto a clean, non-marring surface.

Place Seat Panel (B) on the ground, as shown in picture above.




Attach Front Leg (C) to Seat Panel (B) using Bolts(2) and Washer(4) with Allen Wrench(1). The bolts mounting positions are on the inner side of Seat Panel. **DO NOT FULLY TIGHTEN THE BOLTS.**

Step 3




Turn over the part of step 2 with the assitant of your adult partner.

Attach the partialy assembled Seat Panel (B) with Front Legs (C) to the Backrest (A) as shown above.



Using Bolts(③) and Washer (④) with Allen Wrench(①) to connect the Backrest (A) to Seat Panel (B) as shown above.

DO NOT FULLY TIGHTEN THE BOLTS.



Place the Dining Chair on a LEVEL SURFACE to check for wobbles.

If it wobbles, lift the Dining Chair to some 30cm to 50cm in height from the ground.

Keep your feet and toes well away from the drop zone.

Drop the Dining Chair freely and vertically with the four legs, hitting the ground, all at the same time.

This Drop Test will help to ensure that all the bolts and gaps all reach full alignment status.

Test again for evenness on a LEVEL SURFACE.

If no wobbles are found, slowly and steadily turn the Dining Chair upside down.

Then, proceed to tighten all bolts in a sequential manner.


CAUTION: When tightening these bolts, tighten sequentially.

DO NOT tighten any screw fully and then towards the next one.

This would cause the frame to warp.

If there is still wobbles, loosen the bolts and execute these same drop tests.

WARNING!! IF Dining Chair IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.



Your Dining Chair is ready for use.

The chair can only be used on a flat, level surface.

Questions & Answers about Proposition 65

What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm. These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals.

Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water.

Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

What types of chemicals are on the Proposition 65 list?

The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust.

What does a warning mean?

If a warning is placed on a product label or posted or distributed at a workplace, a business, or in rental housing, the business issuing the warning is aware or believes that it is exposing individuals to one or more listed chemicals.

By law, a warning must be given for listed chemicals unless the exposure is low enough to pose no significant risk of cancer or is significantly below levels observed to cause birth defects or other reproductive harm.

• Where can I get more information on Proposition 65? If you have specific questions on the administration or implementation of Proposition 65, you can contact OEHHA's Proposition 65 program at P65.Questions@oehha.ca.gov, or by phone at (916) 445-6900.