


INSTRUCTION

WICKER OUTDOOR PATIO FURNITURE



After-sales mailbox:
Patiofurniture Serviceteam@outlook.com

NOTICE

Please keep these instructions for future reference.

Dear Customer

- Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. Then follow the entire installation instructions to install!
- When installing, please be careful not to tighten the screws immediately! You need to make sure that all the screws are secured to 80%, then tighten them!
- In order to protect the rattan from harm. and the screw hole from grind, do not use the electric drill, please use the manual screwdriver in the hardware package!

If problem occur unsatisfactorily as follows

- A . The outer box is damaged
- B . The product is damaged / bent / cracked while you open the box
- C . The parts / accessories / assembly tools are missing
- D . The instructions are not clear and can not be referred
- E . The product has functional problems
- F . Other aspects that you are not satisfied with

Please feel free to contact us for help. and provide the following information:Platform/Shop name/Order ID/buyer's name/ receiver's address/Problem description.


(Patiofurniture Serviceteam@outlook.com) will reply within 24 hours and will do our best to resolve the problem for you.










CARE INSTRUCTIONS

- **IMPORTANT!** Always cover the conversation sets with the waterproof cover (**included**) when not in use, or you will get dirty surface.
- To clean the cushion cover, please take out the sponge inside. Follow the care instructions that are sewn into the fabric. Never use solvent-based detergents since these may bleach the material and damage the fabric.
- To clean the metal frame and weaving rattan ,wipe them with clean water.It is not recommended to clean products with a strong cleaner or an abrasive materials, it may discolor or damage the surface.

PART LIST




PART LIST

1  M6*35MM x 36	2  M8 Nut x 24	3  M6 Washer x 38
4  M6*100MM x 2	6  Tool x 1	7  M8 Tool x 1
8  Waterproof Cover x 1	17  x 4	18  M8 Washer x 24

STEP

1

Do not fully tighten the screws. After tightening to approximately 60% of the required force, proceed to the next installation step (ensure the screw is straight and the hole can move slightly before continuing).



1




2PCS

3



2PCS

2



1



3PCS

3





3PCS

STEP



3

Do not fully tighten the screws. After tightening to approximately 60% of the required force, proceed to the next installation step (ensure the screw is straight and the hole can move slightly before continuing).



4



Do not fully tighten the screws. After all screws reach approximately 60% of the required torque, tighten all screws. Reserve screw #4 for final installation; prioritize assembling the other screws first.





STEP

5

Do not fully tighten the screws. After tightening to approximately 60% of the required force, proceed to the next installation step (ensure the screw is straight and the hole can move slightly before continuing).





6



STEP



7

Do not fully tighten the screws. After tightening to approximately 60% of the required force, proceed to the next installation step (ensure the screw is straight and the hole can move slightly before continuing).



8



Do not fully tighten the screws. After all screws reach approximately 60% of the required torque, tighten all screws. Reserve screw #4 for final installation; prioritize assembling the other screws first.





STEP

9

Do not fully tighten the screws. After tightening to approximately 60% of the required force, proceed to the next installation step (ensure the screw is straight and the hole can move slightly before continuing).





10



STEP

11

Do not fully tighten the screws. After all screws reach approximately 60% of the required torque, tighten all screws.



STEP

12

2




24PCS

18




24PCS



STEP

13

17



TIPS

1. In order to increase the toughness of the sofa fixed buckle, please soak it in hot water for 10 minutes before use.
2. When in use, first to snap one side of the buckle into the metal frame, and then force the other side into all the frame.
3. You can freely to make a variety of combinations using the above methods.

AFTER-SALE SERVICE

If you have any suggestions for our products or find that the products have quality problems, please contact us first, our after-sales team will reply you within 24 hours, and we will do our best to give you solutions until you are satisfied.

Guaranteed Customer Service

Your shopping experience is very important to us!

Feel unsatisfied? **Contact us!**

Have any questions? **Contact us!**

Wanna Share how wonderful our smart promakes your home?

Share your pictures with us.

Any suggestions? **Contact us!**


We gotcha back!



Patiofurniture Serviceteam@outlook.com



WICKER OUTDOOR PATIO FURNITURE



After-sales mailbox:
Patiofurniture Serviceteam@outlook.com

NOTICE



Please keep these instructions for future reference.

Dear Customer

- Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. Then follow the entire installation instructions to install!
 - When installing, please be careful not to tighten the screws immediately! You need to make sure that all the screws are secured to 80%, then tighten them!
 - In order to protect the rattan from harm. and the screw hole from grind, do not use the electric drill, please use the manual screwdriver in the hardware package!
- If problem occur unsatisfactorily as follows

- A . The outer box is damaged
- B . The product is damaged / bent / cracked while you open the box
- C . The parts / accessories / assembly tools are missing
- D . The instructions are not clear and can not be referred
- E . The product has functional problems
- F . Other aspects that you are not satisfied with

Please feel free to contact us for help. and provide the following information:Platform/Shop name/Order ID/buyer's name/ receiver's address/Problem description.


(Patiofurniture Serviceteam@outlook.com) will reply within 24 hours and will do our best to resolve the problem for you.




CARE INSTRUCTIONS


- **IMPORTANT!** Always cover the conversation sets with the waterproof cover (**included**) when not in use, or you will get dirty surface.
- To clean the cushion cover, please take out the sponge inside. Follow the care instructions that are sewn into the fabric. Never use solvent-based detergents since these may bleach the material and damage the fabric.
- To clean the metal frame and weaving rattan ,wipe them with clean water.It is not recommended to clean products with a strong cleaner or an abrasive materials, it may discolor or damage the surface.


PART LIST



1  M6*35MM x 24	3  M6 Washer x 100	4  M6*100MM x 4	5  M6 Nut x 32	6  Tool x 1	7  M6 Tool x 1
8  Waterproof Cover x 1	13  M6*15MM x 8	14  5MM x 16	15  M6*30MM x 16	16  M6*45MM x 16	

PART LIST




3  M6 Washer x 12	13  M6*15MM x 8	15  M6*30MM x 4
--	--	--

STEP

1

Do not fully tighten the screws. After tightening to approximately 60% of the required force, proceed to the next installation step (ensure the screw is straight and the hole can move slightly before continuing).



1




2PCS

3



2PCS

2



1



2PCS

3




2PCS

4

STEP

3

Do not fully tighten the screws. After tightening to approximately 60% of the required force, proceed to the next installation step (ensure the screw is straight and the hole can move slightly before continuing). Reserve screw #4 for final installation; prioritize assembling the other screws first.



1




4PCS

3



5PCS


4



1PC

4

Do not fully tighten the screws. After all screws reach approximately 60% of the required torque, tighten all screws.



1




4PCS

3



5PCS

4




1PC

STEP


5

Do not fully tighten the screws. After tightening all screws to approximately 60% of the required torque, then fully tighten all screws.first.



3		4PCS
13		4PCS

6




15		4PCS
3		8PCS
5		4PCS

STEP

7

TIPS: When assembling the chassis and part H the screws are installed from the bottom to the top, which prevents the screws from being too long and blocking the turntable rotation.




When installing the swing arms, pay attention to their length: the longer one should be positioned at the rear, and the shorter one at the front.

STEP

8

Invert the entire product, connect the " i " on the base with rattan board as shown in the diagram.

TIP: When Part I is assembled with the assembled seat section, there is a plastic spacer (#14) in the center of the two.



3		8PCS
5		4PCS
14		4PCS
16		4PCS

STEP

9

Do not fully tighten the screws. After tightening all screws to approximately 60% of the required torque, then fully tighten all screws.first.

3




8PCS

13



8PCS



STEP

10

Do not fully tighten the screws. After tightening all screws to approximately 60% of the required torque, then fully tighten all screws.first.

3




4PCS

15



4PCS



AFTER-SALE SERVICE

If you have any suggestions for our products or find that the products have quality problems, please contact us first, our after-sales team will reply you within 24 hours, and we will do our best to give you solutions until you are satisfied.

Guaranteed Customer Service

Your shopping experience is very important to us!

Feel unsatisfied? **Contact us!**

Have any questions? **Contact us!**

Wanna Share how wonderful our smart promakes your home?

Share your pictures with us.

Any suggestions? **Contact us!**

We gotcha back!




Patiofurniture Serviceteam@outlook.com



Outdoor Fire Table

If you have any questions about the product, please feel free to contact us.

E-Mail: Patiofurnitureserviceteam@outlook.com



After-sales mailbox:
Patiofurnitureserviceteam@outlook.com

NOTICE



Please retain these instructions for future reference.

Dear Customer

● Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. If any parts are missing, please contact us promptly to request replacement parts.

● Then follow the entire installation instructions to install.

● Each part is crucial, so please be careful not to lose any. It is recommended to store parts with different lettered identifiers in separate boxes or bags to avoid confusion during installation.

A . The outer box is damaged

B . The product is damaged / bent / cracked while you open the box

C . The parts / accessories / assembly tools are missing

D . The instructions are not clear and can not be referred

E . The product has functional problems



F . Other aspects that you are not satisfied with

Please feel free to contact us for help, and provide the following information:











Platform/Shop name/Order ID/buyer's name/ receiver's address/Problem description.

(Homefurnitureserviceteam@outlook.com) will reply within 24 hours and will do our best to resolve the problem for you.

HARDWARE LIST


①  M6x15 12 pc	②  M6x30 4 pc	③  M6x35 5 pc	④  Φ6x12 21 pc	⑤  Φ6.5x14x3 1 pc
⑥a  Hex Wrench 1 pc				





PART LIST

A  1 pc	B  1 pc	C  1 pc	D  1 pc	E  1 pc
F  1 pc	G  1 pc	H  1 pc	I  1 pc	N  1 pc

1. Please ensure that all accessories are complete before starting the installation.
 2. Due to the variety of accessories, many accessories may be glued together, please check carefully
 3. If any accessories are missing or damaged, please contact the seller immediately.
- E-Mail: Patiofurniturestserviceteam@outlook.com


STEP 1 Frame Structure



C 	D 	E 	3 
1 pc	1 pc	1 pc	4 pcs
4 	6a 		
4 pcs	1 pc		


STEP 2



Determine the component installation direction based on the positions of holes.




Ⓒ 1 pc	Ⓗ 1 pc	① 8 pcs	④ 8 pcs
Ⓐ 1 pc			



STEP 3




F  1 pc	3  1 pc	4  1 pc	5  1 pc
6a  1 pc			



STEP 4





A  1 pc	1  4 pcs	4  4 pcs	6a  1 pc
---	--	--	--

STEP 5




① 	② 	④ 	⑥a 
1 pc	4 pcs	4 pcs	1 pc

STEP 6




STEP 7




STEP 8

LIGHTING INSTRUCTIONS:

1. Read instructions before lighting;
2. Push and turn the knob to LOW;
3. Hold igniter to light the burner,
release control knob after 15 seconds;
if burner does not light, wait 5 minutes, repeat;
4. Adjust flame to desired flame with the control knob.




Electronic
Ignition



LOW

OFF



HI

AFTER-SALE SERVICE CARD

If you have any suggestions for our products or find that the products have quality problems, please contact us first, our after-sales team will reply you within 24 hours, and we will do our best to give you solutions until you are satisfied.

Guaranteed Customer Service

Your shopping experience is very important to us!
Feel unsatisfied? **Contact us!**
Have any questions? **Contact us!**

Wanna Share how wonderful our smart products makes your home?
Share your pictures with us.
Any suggestions? **Contact us!**
We gotcha back!

✉ Patiofurniture Serviceteam@outlook.com

