APP Instructions

Note: If your APP interface is displayed in Chinese, click the menu in the upper right corner to switch languages

Steps 1 : click "Add" to set the name of the fan light.
Steps 2 and then press the Pair code check button 1-2 times within 5 seconds after the fan is powered on.
If you have any further questions, please contact us directly for professional help with your oder number
Official Email Address: Support@BellaDepot.com

Scan QR code and download APP
Support IOS and Android

风扇灯 Pro
联系我们:info@Jingyuanmicro.com

1 — 🌐 语言

🔲 扫一扫

🈶 我的二维码

选择语言

简体中文
繁體中文
2 — English
русский
Español

取消   确定

📄 用户协议

🛡 隐私政策

当前版本 V1.1.3

Instructions

Pair button. In order to ensure that the application can successfully control the device, please click this button within 5 seconds after the device is powered on. If the device flashes or beeps, it means that the phone has been successfully paired with the device, and then the device can be controlled through the application.

Instructions

or beeps, it means that the phone has been successfully paired with the device, and then the device can be controlled through the application.

🕐 Click to select a time to turn off the device.

🌬 The wind blown by the fan after clicking is like the wind in nature.

🌬 The wind blown by the fan after clicking is suitable for sleep.

Ⓡ The fan will rotate reverse after clicking.

↥ Click to change the direction of the wind.

Ⓕ The fan will rotate forward after clicking.

🌙 When you click, the white light and the yellow light will light up at the same time, but only at 10% of the maximum brightness.

💡 When clicked, the white light and yellow light will light at the same time, and the brightness will be the maximum brightness.

💡 When clicked, only yellow light will light up, and the brightness will be the maximum brightness.

💡 When clicked, only white light will light up, and the brightness will be the maximum brightness.

Instructions

Smart Home

Living room   Bedroom   Study   Kitchen

Device

Unpair button. Click this button within 5 seconds when the device is powered on. If the device flashes or beeps, it means that the phone is unpaired with the device and the phone will not be able to control the device.

When in the room page, long press the device card you can delete the device or change the device name.