



At home in your home

Nest works in 95% of homes that have low voltage systems.



Nest is compatible with:

- 24V heating and cooling systems, including gas, electric, oil, forced air, heat pump and radiant.
- Heating: 1, 2 and 3 stages (W1, W2, W3 wires)
- Cooling: 1 and 2 stages (Y1, Y2)
- Heat pump: with auxiliary and emergency heat (O/B, AUX, E)
- Fan (G)
- Power (C, Rh, Rc)
- Humidifier or dehumidifier (HUM, DEHUM)

Adding a common "C" wire not required in 99% of installations. Wi-Fi required for remote control, software updates and Energy Reports.

Go to **lowes.com/nestworks** to find out if Nest will work in your home. Professional installation recommended for:

- Dual fuel systems (heat pump with furnace)
- · Whole-home humidifiers and dehumidifiers