USER MANUAL

LP846

Compact 1250L Dual

Dual Power/3 AAA



FEATURES

- Rechargeable
- USB-C
- Illuminated Side Button
- Dual-power (3AAA)
- Lanyard

ANSI/PLATO FL1 STANDARD			
MODES	**LUMENS**	**RUN TIME**	**BEAM DISTANCE**
High	1250/1253	2H	122
Medium	697 lm	4H	82
Low	71 lm	9H	29

OPERATION INSTRUCTIONS

On/Off: Press and release the button on the tail cap to turn the light on and off.

Cycle Modes: Press button on tail cap quickly to cycle through modes (High/Medium/Low). If light remains in a single mode for longer than 3-5 seconds, the next press of the button will turn the light off.

BATTERY REPLACEMENT

Charging Instructions: To charge the LP846, rotate the cover near the head of the flashlight to access the USB-C charging port. Insert the USB-C end of the included cable into the port and plug the USB end into a 5V charging block.

Battery Replacement: To use AAA batteries, turn the tail cap counterclockwise to remove it. Take out the rechargeable battery and insert three AAA batteries into the light. Reattach the tail cap.

If the light will not be used for an extended period, remove the batteries and store them in a dry, protected place to help prevent leakage or damage.

PRODUCT WARRANTY

The LP846 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@luxpro.com

14725 S Porter Rockwell Blvd Ste C
Bluffdale, UT 84065