TOOLS REQUIRED





Screwdriver (Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



EASY DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


E.KING PANEL BED



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS










HEADBOARD BOTTOM RAIL 1 pc.





HEADBOARD LEG (R) 1 pc.






HEADBOARD LEG (L) 1 pc.



FOOTBOARD 1 pc.



SLAT 13 pcs.




SUPPORT LEG 300 x 28 x 28mm 8 pcs.



SIDE RAILS 2 pcs.

HARDWARE





BOLT 5/16" x 2" 8 pcs.





SPRING WASHER 5/16" 8 pcs.





FLAT WASHER 5/16" x Ø19 8 pcs.





ALLEN WRENCH 4mm 1 pc.





SCREW #4 x 1-1/4" 26 pcs.

packed in 3 cases

Carton	Disignation		Part	Hardware
	Headboard	1		(a) x8pcs
	Headboard Bottom Rail	2		
	Headboard Leg (R)	3		© x8pcs
	Headboard Leg (L)	4		D x1pc
	Footboard	5		
	Slat	6		(X) (E) x26pcs
	Support Leg	7		
	Side Rails	8		

Part ① x1pc

Part ② x1pc Part ③ x1pc


Part 4 x1pc

Hardware Ax8pcs


Hardware ®x8pcs


Hardware © x8pcs


Hardware © x1pc



Part ① x1pc Part ⑤ x1pc Part ⑧ x2pcs







ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. if the product wobbles or feels loose.double-check all bolts and/or screws are properly tightened and secured.

(v) Keep this handy!


Please retain this instruction manualand any order-related information for future reference.

Lift, don't drag!

To avoid damage to praduct please always LIFT the product when transporling ol adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

TOOLS REQUIRED





Screwdriver (Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



EASY DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything? Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

NIGHTSTAND





- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS





NIGHTSTAND 1 pc.





LEG 4 pcs.

HARDWARE



8 pcs.






SPRING WASHER 5/16" 8 pcs.





FLAT WASHER 5/16" x Ø19 8 pcs.




ALLEN WRENCH 4mm 1 pc.



TIPPING-RESTRIANT 1 set.


1

Part ① x1pc
Part ② x4pcs
Hardware ② x8pcs
Hardware ③ x8pcs
Hardware ② x8pcs
Hardware ① x1pc




2

Part ① x1pc Hardware ② x1set Move nightstand into final position and uses tipping restraint attach to wall.



3



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. if the product wobbles or feels loose.double-check all bolts and/or screws are properly tightened and secured.

(V) Keep this handy!

Please retain this instruction manualand any order-related information for future reference.

Lift, don't drag!

To avoid damage to praduct please always LIFT the product when transporling ol adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.